



ZANTINGH

Auto of flame

Mk8 MM
End User Guide

AUTOFLAME[®]



Mk8 MM

End User Guide



Issued by:
AUTOFLAME ENGINEERING LTD
Unit 1-2, Concorde Business Centre
Airport Industrial Estate, Wireless Road
Biggin Hill, Kent TN16 3YN

Tel: +44 (0)845 872 2000

Fax: +44 (0)845 872 2010

Email: salesinfo@autoflame.com

Website: <http://www.autoflame.com/>

Registered Holder:

Company:

Department:

This manual and all the information contained herein is copyright of Autoflame Engineering Ltd. It may not be copied in the whole or part without the consent of the Managing Director.

Autoflame Engineering Ltd's policy is one of continuous improvement in both design and manufacture. We therefore reserve the right to amend specifications and/or data without prior notice. All details contained in this manual are correct at the time of going to print.

Important Notes

A knowledge of combustion related procedures and commissioning is essential before embarking work on any of the M.M./E.G.A. systems. This is for safety reasons and effective use of the M.M./ E.G.A. system. Hands on training is required. For details on schedules and fees relating to group training courses and individual instruction, please contact the Autoflame Engineering Ltd. offices at the address listed on the front.

Short Form - General Terms and Conditions

A full statement of our business terms and conditions are printed on the reverse of all invoices. A copy of these can be issued upon application, if requested in writing.

The System equipment and control concepts referred to in this Manual MUST be installed, commissioned and applied by personnel skilled in the various technical disciplines that are inherent to the Autoflame product range, i.e. combustion, electrical and control.

The sale of Autoflame's systems and equipment referred to in this Manual assume that the dealer, purchaser and installer has the necessary skills at his disposal. i.e. A high degree of combustion engineering experience, and a thorough understanding of the local electrical codes of practice concerning boilers, burners and their ancillary systems and equipment.

Autoflame's warranty from point of sale is two years on all electronic systems and components.

One year on all mechanical systems, components and sensors.

The warranty assumes that all equipment supplied will be used for the purpose that it was intended and in strict compliance with our technical recommendations. Autoflame's warranty and guarantee is limited strictly to product build quality, and design. Excluded absolutely are any claims arising from misapplication, incorrect installation and/or incorrect commissioning.

Contents

1	OVERVIEW AND BENEFITS.....	1
1.1	Features and Benefits.....	1
1.2	System Example.....	4
1.3	Micro-Modulation (MM).....	5
2	ELECTRICAL SPECIFICATIONS.....	6
2.1	Classifications.....	6
2.2	Inputs and Outputs.....	6
2.3	Cable Specifications.....	8
3	END USER OPERATION.....	9
3.1	Home Screen.....	9
3.1.1	Home Screen Components.....	10
3.1.2	Faults.....	12
3.2	Status Screen.....	13
3.2.1	Status.....	13
3.2.2	Status – History.....	14
3.2.3	Status – Burner Enable/Disable.....	15
3.2.4	Status – Low Flame Hold.....	16
3.2.5	Status – Hand Mode.....	17
3.3	Fuel-Air Screen.....	18
3.3.1	Fuel-Air – Curve.....	18
3.3.2	Fuel-Air – Map.....	19
3.3.3	Fuel-Air – History.....	20
3.4	Flame Safeguard Screen.....	21
3.4.1	Flame Safeguard.....	21
3.4.2	Flame Safeguard – History.....	22
3.5	Channels Screen.....	23
3.5.1	Servomotor.....	23
3.5.2	VSD Channel.....	24

3.6	Gas Pressure Sensor Screen 35	3.6.1 Gas Pressure.....	25
3.6.2	Gas Sensor – History.....		26
3.7	Air Pressure Sensor Screen.....		27
3.7.1	Air Pressure.....		27
3.7.2	Air Sensor – History.....		28
3.8	First Outs.....		29
3.9	System Configuration Screen.....		30
3.9.1	Language Selection.....		31
3.9.2	Options.....		32
3.9.3	Parameters.....		33
3.9.4	Expansion Options.....		34
3.9.5	Set Clock.....		35
3.9.6	Manual.....		36
3.9.7	Commission Data.....		37
3.9.8	Diagnostics		38
3.9.9	System Log.....		39
4	ERRORS AND LOCKOUTS.....		40
4.1	Errors.....		40
4.2	Lockouts.....		44
4.3	Alarms and Warnings.....		49
4.4	Settings Conflicts.....		57
4.5	Forced Commission Reasons.....		62
4.6	Troubleshooting and Further Information.....		64
4.6.1	UV Shutter Faults.....		64
4.6.2	UV Problems.....		64
4.6.3	Snubbers.....		64
4.6.4	Channel Positioning Error.....		65
4.6.5	Input Fault.....		65
6	STANDARDS.....		66

1 OVERVIEW AND BENEFITS

1.1 Features and Benefits

Micro-Modulation (MM) / Flame Safeguard

- Fuel/ air ratio control
- Full colour touch screen
- 120V or 230V standard operation 50/60Hz
- Controls up to 5 servomotors and 2 variable speed drives (VSD/ VFD)
- 4 independent fuel programmes
- Fully adjustable PID load control for temperature or pressure
- Internal flame safeguard – full flame supervision with self-check UV or IR
- Dual flame scanner operation (IR and UV scanners)
- Gas valve train leak supervision and high/low gas pressure monitoring
- Air pressure proving and monitoring
- 128 lockouts, errors, alarms and warnings stored with date, time, phase and reset
- 1000 entry system log stored with date, time and status
- Online diagnostics showing system electronics information
- Single point change for adding, removing and adjusting fuel/air positions on fuel-air curve
- Golden start position for optimum ignition position
- Flue gas recirculation start position
- Variable servomotor travel speed
- Burner control safety times user selectable
- External voltage/current load control and setpoint adjustment
- Outside temperature compensation of boiler setpoint
- Second setpoint and run times scheduling
- Hand/auto/low flame hold firing modes
- Various boiler load detectors available
- Fuel flow metering capability – instantaneous and totalised
- Fuel flow feedback
- Multi-burner capability with synchronised firing rate up to 10 MMs
- 4-20mA (0-20mA) / 0-10V (2-10V) input for external modulation
- 4-20mA (0-20mA) / 0-10V (2-10V) output confirming firing rate
- Fully metered combustion control for commissioning based on equivalence ratio and excess air
- Draft control to maintain stack pressure
- Password protection of all safety related functions
- Infra-red port for upload/download of commission data

1 Overview and Benefits

- 15 First out annunciation inputs
- 4 fuel commission curves possible
- 24 hour history graphical information on MM when powered on
- Custom boiler display configuration

Water Level Control

- Fully modulating feed water control with servomotor and VSD as well pump on/off
- Capacitance probes for patented wave signature level detection
- Water level alarms 2nd low, 1st low, high water and optional pre 1st low and pre-high water
- Conductivity probe for auxiliary 2nd low alarm
- Automatic bottom blowdown with time reduction for blowdown savings
- Continuous modulating top blowdown control to maintain TDS in water
- Steam/ hot water flow metering to calculate flow rates based on temperature sensor

Exhaust Gas Analyser (EGA)

- 3 Parameter trim of O₂, CO₂ and CO
- Analysis of O₂, CO, CO₂, NO, exhaust gas temperature, efficiency and delta temperature
- Optional analysis of NO₂ and SO₂
- Local display for re-calibration, changing cells, user configuration and standalone operation
- Upper/lower offset and absolute limits for O₂, CO, CO₂, NO and exhaust gas temperature
- Six 4-20mA output signal for interface with other controls/chart recorders

Intelligent Boiler Sequencing

- System will sequence hot water boilers or steam boilers via lead/lag distribution
- Fully adjustable user options within the system to tailor sequencing operation to the application
- System control for isolation of valves or pumps (2 port valve operation)
- Standby setpoint and warming for lag boilers via a standby pressure and timing sequence
- Lead boiler and lag boiler warming modes selection

Remote Control and Data Transfer Interface (DTI)

- Direct Modbus communications from MM including remote setpoint and firing rate adjustment, burner enable/disable (without DTI or intelligent boiler sequencing)
- DTI will collect operational data for up to 10 MM modules, 10 EGA modules and 10 universal I/O modules in one communications loop
- Information transmitted via RS422 or Ethernet link to local PC/network for running Autoflame CEMS Audit software


PC Compatible

- Download all commissioning data and controller settings from MM module to a PC
- Upload commission data and controller settings from PC to MM module

Universal Digital and Analogue Input/ Output Module

- Detailed logging inputs and outputs when coupled with Mk7 DTI
- 16 Line voltage inputs (110V/ 230V)
- 6 Analogue inputs and 6 analogue outputs
- 8 Volt free contacts
- Configurable alarms through Mk7 DTTI

1.2 System Example



1.3 Micro-Modulation (MM)

To ensure maximum efficiency and reliability of the boiler plant operation, two requirements are of paramount importance, the air to fuel ratio and the target temperature or pressure:

- The air to fuel ratio must be kept to the minimum to ensure complete combustion within the limitations of the combustion head design. A very high air to fuel ratio will be an indication of high excess air, which decreases the overall efficiency of the boiler. The fuel valve and air damper positions set for this minimum air to fuel ratio along the whole commission curve must be infinitely repeatable to an incredibly high degree of accuracy.
- The target temperature or pressure of the boiler should be monitored by the combustion system and at all times, with exactly the right amount of fuel and air fired to achieve this target value. Irrespective of load changes, the burner/boiler system should be able to meet the target temperature or pressure.

The burner's fuel to air ratio was traditionally governed by mechanical systems which involved multiple cams, shafts and linkages controlled by one motor. The inherent hysteresis that occurred from the system design allowing components to be loose, which made the level of accuracy required impossible. With this poor accuracy, the response of the fuel input to the monitored temperature/ pressure of the boiler meant that the set target value at most times would overshoot or fall short.

The Micro-Modulation module is the basic building block of the Autoflame System. The Autoflame MM module provides an easily programmable and flexible means of optimising combustion quality throughout the load requirement range of the burner/boiler unit whilst ensuring the temperature is accurate to within 1 °C (°F) and pressure to within 1 PSI (0.1Bar). Using direct drive motors to individually control the air damper and fuel valve(s), gives the optimum combustion of the burner at every point along the firing range. The allowed error in angular degrees of rotation between the two servomotors at any position in the load range is 0.1 °.

This automated system of burner control can achieve 'locked on' near stoichiometric air to fuel mixing throughout the fuel input range of the boiler while maintaining exact temperature or pressure target values. The load control incorporates user-variable Proportional Integral Derivative control. The PID control is infinitely adjustable to match any boiler room requirements.

2 ELECTRICAL SPECIFICATIONS

2.1 Classifications

Classification according to BS EN298:2012

Mains Supply:	Single phase 230V, +10%/-15%} Single phase 120V, +10%/-15%}	47-63 Hz, unit max. consumption 140W
Climate:	Min. Temperature Recommended Temperature Max. Temperature Humidity	0°C (32°F) Less than 40°C (104°F) 60°C (140°F) 0 to 90% non-condensing
Storage:	Temperature	-20 to 85°C (-4 to 185°F)
Protection Rating:	The unit is designed to be panel mounted in any orientation and the front facia is IP65, NEMA4. The back of the unit is IP20, NEMA1.	

2.2 Inputs and Outputs

MM Inputs and Outputs

230V Unit:

Outputs	Terminal	57	250mA	Must be connected through contactor	
		58	250mA	Must be connected through contactor	
		59	1A	0.6 power factor	
		60	1A	0.6 power factor	
		61	1A	0.6 power factor	Max Load 6A
		62	1A	0.6 power factor	
		63	1A	0.6 power factor	
		78	100mA	To drive relay only - switched neutral	
		79	100mA	To drive relay/lamp only - switched neutral	

120V Unit:

Outputs	Terminal	57	250mA	Must be connected through contactor	
		58	250mA	Must be connected through contactor	
		59	2A	0.6 power factor	
		60	2A	0.6 power factor	
		61	2A	0.6 power factor	Max Load 6A
		62	2A	0.6 power factor	
		63	2A	0.6 power factor	
		78	100mA	To drive relay only - switched neutral	
		79	100mA	To drive relay/lamp only - switched neutral	

2 Electrical Specifications

Expansion Board Inputs and Outputs

Outputs: 120/230 V All outputs with the exception of PF are switched neutrals

BFW	250mA	Must be connected through contactor
BB	250mA	Must be connected through contactor
HWV	100mA	(alarm indicator)
2LA	100mA	(alarm indicator)
2LV	100mA	(alarm indicator)
H1A	100mA	(alarm indicator)
1LV	100mA	(alarm indicator)
79	100mA	(alarm indicator on MM board)
TB	250mA	Solenoid only, must be connected through contactor
PF	Maximum 2A	(load currents for above terminals)

Note: Max number of alarm indicators on at any time is 3 (1LV, 2LA, 2LV)

Main Voltage Signal Inputs:

At 120V current loading is approximately maximum 0.7mA per input.

At 230V current loading is approximately maximum 1.5mA per input.

Note:

1. The high and low voltage connections are not safe to touch. Protection against electric shock is provided by correct installation. **CAUTION – ELECTRIC SHOCK HAZARD.**
2. Control voltage cabling should be maximum 10m, screened (if not screened then less than 1m, however servomotors can be unscreened up to 10m)
3. Any cabling over 10m must have additional surge protection.
4. Low voltage cables should be screened cable as specified in section 2.3.
5. The burner 'High Limit Stat' must be a manual reset type.

Note: There is a lid (back plate) fitted onto the back of the Mk8 MM with a Warning label to prevent any unauthorised fuse replacements.

2.3 Cable Specifications

Low Voltage

The screened cable used for low voltage wiring from the MM to the servomotors, detectors and variable speed drive must conform to the following specification:

U.V. cable length should not exceed 25m, all other screened cable should not exceed 50m.

16/0.2mm PVC insulated overall braid, screened, PVC sheathed.

- Sixteen wires per core
- Diameter of wires in each core 0.2mm
- Rated at 440V AC rms at 1600Hz
- DEF 61-12 current rating per core 2.5A
- Maximum operating temperature 70°C (158°F)
- Nominal conductor area 0.5sq mm per core
- Nominal insulation radial thickness on core 0.45mm
- Nominal conductor diameter per core 0.93mm
- Nominal core resistance at 20°C. 40.1Ω/1000m
- Nominal overall diameter per core 1.83mm
- Fill factor of braid screen 0.7
- Equivalent imperial conductor sizes 14/0.0076

Use the number of cores suitable for the application. A universal part numbering system appears to have been adopted for this type of cable as follows:

16-2-2C 2 Core
16-2-3C 3 Core
16-2-4C 4 Core
16-2-6C 6 Core
16-2-8C 8 Core

(5 Core not readily available)

Note: If using 4 Core cable and interference is detected, use 2 sets of 2 Core.

Data Cable

Data cable must be used for communication connections between MMs for sequencing applications as well as between MMs to EGAs, MMs to a DTI and DTI to BMS systems.

Communication cable should not exceed 1km.

Types of data cable that can be used:

- 1 Beldon 9501 for 2-core shielded cable (1 twisted pair)
- 2 Beldon 9502 for 4-core shielded cable (2 twisted pairs)
- 3 STC OS1P24

Samples are available upon request. Low voltage and data cable can be ordered directly from Autoflame Engineering, please contact Autoflame Sales.

When using a VSD, please review the manufacturer's guidelines on installations to prevent EMC including the recommendations for reactors and filters.

3 END USER OPERATION

3.1 Home Screen







Figure 3.1.i Home Screen

The home screen shown in Figure 3.1.i displays the current boiler setup. It provides operation information for each component of the burner/boiler in real time. Pressing on components will display further information e.g. pressing on the servomotor image will show the servomotor position history. This boiler room setup can be configured to display what is actually on site, please see section 3.19.5 Boiler Room Configuration.


3.1.1 Home Screen Components

	Servomotor		Variable speed drive
	Flame scanner		Oil pressure sensor
	Air pressure sensor/ boiler steam pressure detector		Gas pressure sensor
	Boiler temperature detector/ outside temperature sensor		Feed water temperature sensor
	Main fuel valve open		Main fuel valve closed
	Pilot gas valve open		Pilot gas valve closed
	Control fuel valve open		Control fuel valve closed
	Main gas regulator		Pilot gas regulator
	Gas flowing		No gas flowing
	Oil flowing		No oil flowing
	Combustion air fan		Induced draught fan
	Gas flame		Oil flame
	Capacitance probes		2 nd Low conductivity probe
	External level sensor for water level		Steam header
	TDS probe		Feed water pump

3 End User Operation



IBS
Information



Three Pass
Fire Tube

3.1.2 Faults

Lockouts	Phase	Occurred	Reset
1. VPS air proving fail	VPS Air Proving	14 Dec 15 12:21	14 Dec 15 12:21
2. VPS air zeroing	VPS Air Proving	14 Dec 15 12:21	14 Dec 15 12:21
3. Gas pressure low limit	VPS Gas Proving	14 Dec 15 12:19	14 Dec 15 12:19
4. VPS air zeroing	VPS Air Proving	14 Dec 15 11:43	14 Dec 15 11:43
5. Air Sensor Comms	Recycle	14 Dec 15 11:35	14 Dec 15 11:37
6. Air Sensor Comms	Recycle	14 Dec 15 09:49	14 Dec 15 11:18
7. Air Sensor Comms	Recycle	14 Dec 15 09:49	14 Dec 15 09:49
8. Air Sensor Comms	Recycle	11 Dec 15 11:52	11 Dec 15 12:18
9. Air Sensor Comms	Recycle	11 Dec 15 11:51	11 Dec 15 11:52
10. Air Sensor Comms	Recycle	11 Dec 15 11:51	11 Dec 15 11:51
11. Air Sensor Comms	Recycle	11 Dec 15 11:42	11 Dec 15 11:48
12. Air Sensor Comms	Recycle	11 Dec 15 11:40	11 Dec 15 11:42
13. Air Sensor Comms	Recycle	11 Dec 15 11:40	11 Dec 15 11:40
14. Air Sensor Comms	Recycle	11 Dec 15 11:40	11 Dec 15 11:40
15. Air Sensor Comms	Recycle	11 Dec 15 09:33	11 Dec 15 10:06
16. Air Sensor Comms	Recycle	11 Dec 15 09:33	11 Dec 15 09:33
17. Air Sensor Comms	Recycle	10 Dec 15 16:21	10 Dec 15 16:22
18. Wait Air Switch timeout	Wait Air Switch	10 Dec 15 12:07	10 Dec 15 12:54
19. No air proving	Purge	10 Dec 15 10:04	10 Dec 15 10:04
20. VPS air zeroing	VPS Air Proving	10 Dec 15 09:53	10 Dec 15 10:03
21. VPS air zeroing	VPS Air Proving	10 Dec 15 09:51	10 Dec 15 09:53
22. VPS air zeroing	VPS Air Proving	10 Dec 15 09:39	10 Dec 15 09:51

Lockouts
Errors
Alarms
Warnings
First outs

Figure 3.1.2.i Lockouts

Press in the Home screen to view the faults, which are categorised into lockouts, errors, alarms, warning and first out alarms, and are access by pressing on the corresponding tabs.

Fault	Type	Shuts Down Burner	Reset By
Lockout	Burner control fault	Yes	Reset button or input on T56
Error	Internal or hardware fault	Yes	Power cycle
Alarm	Critical system fault	Yes	Reset button or input
Warning	Non-critical fault	No	Reset button
First out	Configurable fault	Optional	Reset button/ auto

3.2 Status Screen

3.2.1 Status




Figure 3.2.1.i Status

Press on the boiler load detector or the boiler image in the Home screen (Figure 3.1.i) to display the Status screen, which gives the following information:

- Burner rating
- Current fuel selected and type
- Burner starts and run hours
- Current firing rate
- Control method – internal PID control, external modulation or DTI/remote firing rate
- Actual temperature/pressure reading from load detector
- Current setpoint – required, reduced, DTI or external
- Stat status – running interlock T53/ internal stat
- Burner switch on/off offset
- Reduced setpoint
- Indication if MM is firing to meet required or reduced setpoint (red = active, grey = inactive)
- Arrows for adjusting setpoint

Press the   arrows to change the required or reduced setpoints. If these arrows are not displayed, then either the user setpoint change has been disabled (option 15), the DTI is controlling the setpoint (option 16), external setpoint is enabled (parameter 72), or OTC is enabled (option 80).

Note: Use parameters 29 and 30 to adjust the load detector reading if required.

3.2.2 Status – History




Figure 3.2.2.i Status – History

Press  in the Status screen in Figure 3.2.1.i to show the Status History. The setpoint, actual temperature/pressure and firing rate are displayed graphically.

This data is logged for 24 hours on the MM. Use the   buttons to change the timescale of the data displayed, and press and drag on the axis to zoom in/out of the graph.

This information is logged for 2 years on the DTI when connected with the MM.

Note: Power cycling the MM or changing fuel will reset the 24 hour history data log on the MM.

3.2.3 Status – Burner Enable/Disable




Figure 3.2.3.i Status – Burner Enable/Disable

Press and hold  for 3 seconds in the Status screen in Figure 3.2.1.i to disable the burner. Press and hold this same button to enable the burner.

3.2.4 Status – Low Flame Hold




Figure 3.2.4.i Status – Low Flame Hold

Press and hold  for 3 seconds in the Status screen in Figure 3.2.2.i to put the MM in low flame hold. Press and hold this button again to return to normal modulation.

Alternatively, the Mk8 MM can also be put in low flame hold via an input on terminal 95.

If low flame hold or hand mode is selected on the MM screen, this will override an input made on terminal 94 or 95.

Note: If using intelligent boiler sequencing, then putting the MM into low flame hold will remove the MM from the sequence loop. It will resume sequencing once low flame hold is deselected and after the next scan time elapses.

Note: If low flame hold and hand mode are both selected, then hand mode takes priority.

3.2.5 Status – Hand Mode




Figure 3.2.5.i Status – Hand Mode

Press and hold  for 3 seconds in the Status screen in Figure 3.2.1.i to put the MM into hand mode, where the firing rate can be driving up or down by using the  arrows.

Alternatively, the MM can be put into hand mode by an input on terminal 94.

If low flame hold or hand mode is selected on the MM screen, this will override an input made on terminal 94 or 95.

Note: If using intelligent boiler sequencing, then putting the MM into hand mode will remove the MM from the sequence loop. It will resume sequencing once hand mode is deselected and after the next scan time elapses.

Note: If low flame hold and hand mode are both selected, then hand mode takes priority.

Note: If a firing rate limit is set (option 66), then the firing cannot be driven past this in hand mode.

3.3 Fuel-Air Screen

3.3.1 Fuel-Air – Curve




Figure 3.3.1.i Fuel-Air – Curve

Press the flame in the Home screen in Figure 3.1.i to view the Fuel-Air screen, which shows current servomotor and VSD output positions, the trim status and the commission curve graph.

3.3.2 Fuel-Air – Map




Figure 3.3.2.i Fuel-Air – Map

Press **Map** in the Fuel-Air screen in Figure 3.3.1.i to view the commissioned trim values if an EGA has been enabled with trim. The air rich (A+) and fuel rich (A-) values are shown for each commissioned point on the fuel-air curve, for the O₂, CO and CO₂. The graph shows the EGA's current readings and if there is any trim correction on the air damper. The circle on the fuel-air map indicates the current position of the trim correction, and how far the current combustion values are from the commissioned values.

Note: Option 12 must be set to 2 or 3 for the 3-parameter trim function to be activated.

3.3.3 Fuel-Air – History




Figure 3.3.3.i Fuel-Air – History

Press **History** in the Fuel-Air screen in Figure 3.3.1i to view the Fuel-Air History screen, which shows the firing rate and air trim history.

Note: Option 12 must be set to 2 or 3 for the 3-parameter trim function to be activated.

This data is logged for 24 hours on the MM. Use the **Zoom In** **Zoom Out** buttons to change the timescale of the data displayed, and press and drag on the axis to zoom in/out of the graph.

This information is logged for 2 years on the DTI when connected with the MM.

Note: Power cycling the MM or changing fuel will reset the 24 hour history data log on the MM.

3.4 Flame Safeguard Screen

3.4.1 Flame Safeguard




Figure 3.4.1.i Flame Safeguard

Press on the flame scanner in the Home screen in Figure 3.1.i to view the Flame Safeguard screen, which shows the current firing phase of the MM, pilot type and flame scanner signal strength.

Throughout the entire burner start-up and firing sequence, the vertical dotted line will move horizontally showing which phase the burner is at currently. The rows refer to:

- Post purge
- Pre purge
- Air damper position
- Main fuel valve
- Pilot fuel valve
- Ignition
- Blower motor

Note: If a flame switch is used for flame detection, then flame switch show as either on (flame detected) or off (no flame detected).

Please refer to section **XX** for the start-up sequence of the burner.

3.4.2 Flame Safeguard – History




Figure 3.4.2.i Flame Safeguard - History

Press  in the Flame Safeguard screen in Figure 3.4.1.i to view the Flame Safeguard History, showing the flame scanner signal and firing rate.

This data is logged for 24 hours on the MM. Use the   buttons to change the timescale of the data displayed, and press and drag on the axis to zoom in/out of the graph.

This information is logged for 2 years on the DTI when connected with the MM.

Note: Power cycling the MM or changing fuel will reset the 24 hour history data log on the MM.

3.5 Channels Screen

3.5.1 Servomotor




Figure 3.5.1.i Servomotor

Press on a servomotor in the Home screen in Figure 3.1.i to view the Channels screen, which shows the current servomotor positions and VSD outputs and inputs.

This data is logged for 24 hours on the MM. Use the   buttons to change the timescale of the data displayed, and press and drag on the axis to zoom in/out of the graph.

This information is logged for 2 years on the DTI when connected with the MM.

Note: Power cycling the MM or changing fuel will reset the 24 hour history data log on the MM.

3.5.2 VSD Channel




Figure 3.5.2.i VSD Channel

Press  or  in the Channels screen in Figure 3.5.1.i to view the VSD Channel 5 or VSD Channel 6 output and input history, respectively. Alternatively, pressing on the VSD in the Home screen in Figure 3.1.i will also display the VSD Channel screen.

This data is logged for 24 hours on the MM. Use the  buttons to change the timescale of the data displayed, and press and drag on the axis to zoom in/out of the graph.

This information is logged for 2 years on the DTI when connected with the MM.

Note: Power cycling the MM or changing fuel will reset the 24 hour history data log on the MM.

3.6 Gas Pressure Sensor Screen

3.6.1 Gas Pressure




Figure 3.6.1.i Gas Pressure

Press on the gas pressure sensor (if enabled) in the Home screen in Figure 3.1.i to view the gas pressure screen, which shows the following information:

- Commissioned gas pressure for the corresponding point on fuel-air curve
- Actual (current) gas pressure
- Valve proving gas pressure
- Status of main gas and vent valves
- Upper/lower offset gas pressure limits for fuel-air curve

3.6.2 Gas Sensor – History




Figure 3.6.2.i Gas Sensor – History

Press  in the Gas Pressure screen in Figure 3.6.1.i to view the Gas Pressure History screen, showing the commissioned and actual gas pressure histories.

This data is logged for 24 hours on the MM. Use the   buttons to change the timescale of the data displayed, and press and drag on the axis to zoom in/out of the graph.

This information is logged for 2 years on the DTI when connected with the MM.

Note: Power cycling the MM or changing fuel will reset the 24 hour history data log on the MM.

3.7 Air Pressure Sensor Screen

3.7.1 Air Pressure




Figure 3.7.1.i Air Pressure

Press on the air pressure sensor in the Home screen in Figure 3.1.i to view the Air Pressure screen, which shows the expected air pressure, actual (current) air pressure and the difference between these values, for the corresponding point on the fuel-air curve.

The graph shows the commissioned air pressure for the fuel-air curve and the upper/lower offset limits, as well as the air pressure values with trim function enabled on the air damper.

If commissioned with an EGA, the air pressure is stored during the commissioning the trim function, and shown as the red line on the graph.

3.7.2 Air Sensor – History




Figure 3.7.2.i Air Sensor – History

Press  in the Air Pressure screen in Figure 3.7.1.i to view the Air Pressure History screen, showing the commissioned and actual air pressure histories.

This data is logged for 24 hours on the MM. Use the   buttons to change the timescale of the data displayed, and press and drag on the axis to zoom in/out of the graph.

This information is logged for 2 years on the DTI when connected with the MM.

Note: Power cycling the MM or changing fuel will reset the 24 hour history data log on the MM.

3.8 First Outs

First Out Label	Function	Active State
1. First Out 1	Monitor	Active High
2. First out 2	Monitor	Active High
3. First out 3	Non-recycle	Active High
4. First out 4	Non-recycle	Active High
5. First out 5	Recycle	Active High
6. First out 6	Recycle	Active High
7. First out 7	Monitor	Active High
8. First out 8	Non-recycle	Active High
9. First out 9	Recycle	Active High
10. First out 10	Monitor	Active High
11. First out 11	Non-recycle	Active High
12. First out 12	Recycle	Active High
13. First out 13	Disabled	Active High
14. First out 14	Monitor	Active High
15. First out 15	Non-recycle	Active High



Figure 3.17.i First Outs

Press  (if enabled) in the Home Screen in Figure 3.1.i to view the First Outs screen. The functions of a first out when active is summarised below:

Function When Active	Description
Disabled	Does not function.
Monitor	Burner continues firing, but the events will be logged.
Non-recycle	Burner stops firing and the first out must be reset for the burner to restart.
Recycle	Burner stops firing and restarts automatically when the input state changes.
Stop EGA Sampling	Burner continues firing, but the EGA stops sampling.
Stops EGA Trimming	Burner continues firing, but the EGA trim stops operating.

3.9 System Configuration Screen




Figure 3.19.i

Press  in the Home screen in Figure 3.1.i to access the System Configuration screen. From this screen it is possible to:

- Change language (password protected)
- View all options
- View all parameters
- View all expansion options
- Change boiler configuration display in Home screen (password protected)
- Access online changes (password protected)
- Access single point change (password protected)
- Set clock (password protected)
- Set run times (password protected)
- Set bottom blowdown schedule if enabled (password protected)
- View operating manual
- View commission data
- View real-time diagnostics
- View system log

In the top left corner, the serial number and bootloader of the MM are shown, and in the top right, the BC, MM and Display software versions are shown.

3.9.1 Language Selection




Figure 3.19.1.i Language Selection

Press  in the System Configuration screen in Figure 3.19.i to access Language Selection screen; you will be prompted to enter the Online Changes password. Please contact your local approved Autoflame tech centre for this password.

Note: The SD card must contain the language file to be able to select the language. If a language required is not available, please contact the Autoflame office.

3.9.2 Options

Read Only		
Options	Parameters	Expansion
#	Description	Value
1	MM: Boiler Temperature/Pressure Sensor Type	Medium pressure (MM10008, 0 – 20bar / 300psi)
2	MM: Modulating Motor Travel Speed Limit	1.5
3	Unused: Option 3	0
4	Unused: Option 4	0
5	MM: Purge Position	Channels 1 to 4 purge at OPEN position
6	PID: Proportional Band	1.0 bar
7	PID: Integral Time	60 seconds
8	MM: Servomotor Channels	Channels 1, 2, 3, & 4
9	MM: Internal Stat Operation	Burner operates below setpoint
10	MM: Burner Switch-Off Offset	0.3 bar
11	MM: Burner Switch-On Offset	0.3 bar
12	EGA: EGA Functionality	Applies trim
13	EGA: EGA Fault Response	EGA faults generate Warnings (Burner runs)
14	MM: Warning Response	Warnings drive Common System Alarm output (T79)
15	MM: User Control	Burner on/off and setpoint control enabled
16	DTI: Sequencing and DTI enable	Sequencing and DTI
17	Unused: Option 17	0
18	EGA: Carry Forward of Trim	Enabled
19	EGA: O2 Upper Limit Offset	Disabled

All	MM	PID	EGA	DTI	BC
-----	----	-----	-----	-----	----





Figure 3.19.2.i Options

Press  in the System Configuration screen in Figure 3.19.i to view the Options screen, which displays all of the options and their ranges and settings. This is a read only mode, so no changes can be made to the options in this screen. Options highlighted in blue are ones which have been changed from the default values.

Press on the MM, PID, EGA, DTI and BC tabs to group together options in those categories.

3.9.3 Parameters

Read Only			
Options		Parameters	Expansion
#	Description	Value	
1	DTI: Sequence Scan Time Set When Unit Goes Offline	3 minutes (00:03:00)	
2	Unused: Parameter 2	0	
3	DTI: Number of Boilers Initially On	4	
4	EGA: Delay Before EGA Commission Can Be Stored	45 seconds	
5	DTI: Modulation Timeout	4 minutes (00:04:00)	
6	Unused: Parameter 6	0	
7	Unused: Parameter 7	0	
8	EGA: Trim Delay After Drain	40 seconds	
9	Unused: Parameter 9	0	
10	EGA: EGA Version	Mk8	
11	Unused: Parameter 11	0	
12	EGA: CO Used For Trim On Oil	Disabled	
13	EGA: Commission Fuel-Rich Trim	5.0 %	
14	EGA: Trim Reset Angular Rate	5.0 degrees per minute	
15	MM: Golden Start Time	5 seconds	
16	EGA: (Mk7 Only) Time Between Air Calibrations	6.0 hours	
17	EGA: Number Of Trims Before Limits Error Generated	3	
18	EGA: Maximum Trim During Run	10.0 %	
19	EGA: Commission Air-Rich Trim	5.0 %	

All	MM	PID	EGA	DTI	BC
-----	----	-----	-----	-----	----





Figure 3.19.3.i Parameters

Press  in the System Configuration screen in Figure 3.19.i to view the Parameters screen, which displays all of the parameters and their ranges and settings. This is a read only mode, so no changes can be made to the parameters in this screen. Parameters highlighted in blue are ones which have been changed from the default values.

Press on the MM, PID, EGA, DTI and BC tabs to group together parameters in those categories.

3.9.4 Expansion Options

Options		Parameters	Expansion
#	Description	Value	
1	WLC: Water Level Control Function	Water Level Control Enabled	
2	WLC: Feedwater Control Element	Pump On/Off and Servo Control	
3	WLC: Capacitance Probes	Two Capacitance Probes	
4	WLC: External Level Sensor	External Level Sensor Enabled	
5	WLC: Auxiliary Alarm Inputs	Auxiliary Alarm Inputs Enabled	
6	WLC: Second Low Probe	Second Low Probe Enabled	
7	WLC: Pre-High Alarm Percentage	50 %	
8	WLC: Pre-First-Low Alarm Percentage	60 %	
9	WLC: Burner Operation at High Water	Burner Stops at High Water	
10	WLC: Pump Turn Off Point	Pump Turns Off Above Control Point	
11	WLC: Pump Turn Off Percentage	30 %	
12	WLC: Pump Turn On Percentage	10 %	
13	WLC: Feedwater Control Proportional Band	50 %	
14	WLC: Feedwater Control Integral Time	20 seconds	
15	WLC: Feedwater Control Derivative Time	Disabled	
16	WLC: Feedwater Servo Open Angle	90.0 °	
17	WLC: Pump Bypass Operation	Pump Bypass Disabled	
18	WLC: Pump Bypass Switch Point	20 %	
19	WLC: Pump Bypass Hysteresis	5 %	

All
WLC
TBD
BBD
DC
Modbus
FO
Flow
FM

Figure 3.19.4.i Expansion Options

Press in the System Configuration screen in Figure 3.19.i to view the Expansion Options screen, which displays all of the expansion options and their ranges and settings. This is a read only mode, so no changes can be made to the expansion options in this screen. Expansion options highlighted in blue are ones which have been changed from the default values.

Press on the MM, PID, EGA, DTI and BC tabs to group together expansion options in those categories.

3.9.5 Set Clock




Figure 3.19.7.i Set Clock

Press  in the System Configuration screen in Figure 3.19.i to access the Set Clock screen; you will be prompted to enter the password (10, 10). Change the time and data using the   arrows and then press  and then press .

Note: If the MM is connected to a DTI, then then time and data will be set by the DTI and cannot be adjusted on the MM.

3.9.6 Manual




Figure 3.19.10.i Manual

Press  in the System Configuration screen in Figure 3.19.i to view the Manual screen. Press on the section headings to navigate through the operating manual.

Note: The SD card must contact the manual file to be able to view the operating manual on the MM screen.

3.9.7 Commission Data




Figure 3.19.11.i Commission Data

Press  in the System Configuration screen in Figure 3.19.i to view the Commission Data screen.

3.9.8 Diagnostics

Diagnostics							
#	Description						Value
1	System: Processor temperature (Now)						39.0 °C
2	System: Processor temperature (Min)						9.8 °C
3	System: Processor temperature (Max)						48.2 °C
4	System: Mains frequency (Now)						50.075 Hz
5	System: Mains frequency (Min)						45.000 Hz
6	System: Mains frequency (Max)						55.991 Hz
7	System: Digital supply voltage (Now)						3.311 V
8	System: Digital supply voltage (Min)						3.297 V
9	System: Digital supply voltage (Max)						3.317 V
10	System: Analogue supply voltage (Now)						12.000 V
11	System: Analogue supply voltage (Min)						11.851 V
12	System: Analogue supply voltage (Max)						12.148 V
13	System: Expansion analogue supply voltage (Now)						12.000 V
14	System: Expansion analogue supply voltage (Min)						11.683 V
15	System: Expansion analogue supply voltage (Max)						12.137 V
16	System: Mains RMS voltage (Now)						241.2 V
17	System: Mains RMS voltage (Min)						72.9 V
18	System: Mains RMS voltage (Max)						252.8 V
19	System: Mains RMS current (Now)						0.242 A
20	System: Mains RMS current (Min)						0.089 A
All	System	PID	Trim	Water			





Figure 3.19.12.i Diagnostics

Press  in the System Configuration screen in Figure 3.19.i to view the real-time diagnostics. This data is logged hourly on the SD card for up to 3 months. The minimum and maximum values are the lowest and highest values the MM as detected for this measurement.

3.9.9 System Log

System Log	Detail	Occurred
1. Stat Turn On		8 Mar 17 09:00
2. Stat Turn Off	Burner Disable	8 Mar 17 08:59
3. Stat Turn On		8 Mar 17 08:55
4. MM Started	Fuel 1	8 Mar 17 08:54
5. FAR Restarted		8 Mar 17 08:54
6. Parameter 118 Changed	From 0 to 10	8 Mar 17 08:54
7. Option 118 Changed	From 0 to 10	8 Mar 17 08:54
8. Abnormal Shutdown		8 Mar 17 08:53
9. MM Started	Fuel 1	8 Mar 17 08:53
10. Stat Turn On	Burner Disable	8 Mar 17 08:50
11. Stat Turn Off	Burner Disable	8 Mar 17 08:49
12. Stat Turn On	Burner Disable	8 Mar 17 08:46
13. Stat Turn Off	Burner Disable	8 Mar 17 08:46
14. Run-Times Disabled		8 Mar 17 08:43
15. Run-Times Enabled		8 Mar 17 08:42
16. Run-Times Disabled		8 Mar 17 08:42
17. Run-Times Enabled		8 Mar 17 08:42
18. Stat Turn On		8 Mar 17 08:17
19. Stat Turn Off		8 Mar 17 08:17
20. Stat Turn On		8 Mar 17 08:17
21. Stat Turn Off		8 Mar 17 08:17
22. Stat Turn On		8 Mar 17 08:16

All
Faults
MM
Water
Config





Figure 3.19.13.i System Log

Press  in the System Configuration screen in Figure 3.19.i to view the System Log screen, which stores 1000 entries of the following information:

- Stat on/ off
- Setting changes
- Commission/single point change
- Fuel flow commission
- MM restart
- Setpoint changes

4 ERRORS AND LOCKOUTS

4.1 Errors

Errors occur when the MM detects an internal fault, component out of range, internal check failure or power supply issue. To clear an error, the MM must be restarted.

Error	Message	Description
1	Channel 1 Positioning Error	Servomotor is outside of the commissioned range
		<ul style="list-style-type: none"> • Check wiring on terminals 40 - 47 • Check signal cable from the MM to the servomotor is screened at one end • Check potentiometer is zeroed correctly • Go into Commissioning mode, check the servomotor position and ensure that closed is at 0.0°
2	Channel 2 Positioning Error	Servomotor is outside of the commissioned range
		<ul style="list-style-type: none"> • Check wiring on terminals 40 - 47 • Check signal cable from the MM to the servomotor is screened at one end • Check potentiometer is zeroed correctly • Go into Commissioning mode, check the servomotor position and ensure that closed is at 0.0°
3	Channel 3 Positioning Error	Servomotor is outside of the commissioned range
		<ul style="list-style-type: none"> • Check wiring on terminals 40 - 47 • Check signal cable from the MM to the servomotor is screened at one end • Check potentiometer is zeroed correctly • Go into Commissioning mode, check the servomotor position and ensure that closed is at 0.0°
4	Channel 4 Positioning Error	Servomotor is outside of the commissioned range
		<ul style="list-style-type: none"> • Check wiring on terminals 40 - 47 • Check signal cable from the MM to the servomotor is screened at one end • Check potentiometer is zeroed correctly • Go into Commissioning mode, check the servomotor position and ensure that closed is at 0.0°
5	Channel 7 Positioning Error	Servomotor is outside of the commissioned range
		<ul style="list-style-type: none"> • Check wiring on terminals DP-, DP+, DPW • Check signal cable from the MM to the servomotor is screened at one end • Check potentiometer is zeroed correctly • Go into Commissioning mode, check the servomotor position and ensure that closed is at 0.0°
6	Channel 1 Gain Error	Servomotor position measurement hardware error
		<ul style="list-style-type: none"> • Check wiring and voltages on terminals 40 - 47 and 70 - 77
7	Channel 2 Gain Error	Servomotor position measurement hardware error
		<ul style="list-style-type: none"> • Check wiring and voltages on terminals 40 - 47 and 70 - 77
8	Channel 3 Gain Error	Servomotor position measurement hardware error
		<ul style="list-style-type: none"> • Check wiring and voltages on terminals 40 - 47 and 70 - 77
9	Channel 4 Gain Error	Servomotor position measurement hardware error
		<ul style="list-style-type: none"> • Check wiring and voltages on terminals 40 - 47 and 70 - 77
10	Channel 7 Gain Error	Servomotor position measurement hardware error
		<ul style="list-style-type: none"> • Check wiring and voltages on terminals DP-, DP+, DPW and DCI, DCD
11	Channel 1 Movement Error	Servomotor moves when not expected and vice versa
		<ul style="list-style-type: none"> • Check wiring and voltages on terminals 70 - 77 • Check servomotors drive in correct direction and valve is not stuck

4 Errors and Lockouts

Error	Message	Description
12	Channel 2 Movement Error	Servomotor moves when not expected and vice versa
		<ul style="list-style-type: none"> • Check wiring and voltages on terminals and 70 - 77 • Check servomotors drive in correct direction and damper is not stuck
13	Channel 3 Movement Error	Servomotor moves when not expected and vice versa
		<ul style="list-style-type: none"> • Check wiring and voltages on terminals and 70 - 77 • Check servomotors drive in correct direction and valve is not stuck
14	Channel 4 Movement Error	Servomotor moves when not expected and vice versa
		<ul style="list-style-type: none"> • Check wiring and voltages on terminals and 70 - 77 • Check servomotors drive in correct direction and valve is not stuck
15	Channel 7 Movement Error	Servomotor moves when not expected and vice versa
		<ul style="list-style-type: none"> • Check wiring and voltages on terminals DCI and DCD • Check servomotor drives in correct direction and damper is not stuck
16	Analogue Power Supply Error	ADC measured 12V supply out of range
		<ul style="list-style-type: none"> • Check wiring for shorts on terminals 41, 47 and 39
17	Digital Power Supply Error	ADC measured 3.3V supply out of range
		<ul style="list-style-type: none"> • Check for noise on the mains input, wiring and voltages on all terminals
18	EEPROM Error	Fault communicating with the on board EEPROM
		<ul style="list-style-type: none"> • Contact Autoflame approved local tech centre
19	ADC Error	Internal fault
		<ul style="list-style-type: none"> • Contact Autoflame approved local tech centre
20	Watchdog Timeout	Internal fault
		<ul style="list-style-type: none"> • Contact Autoflame approved local tech centre
21	Processor Clock Error	Internal fault
		<ul style="list-style-type: none"> • Contact Autoflame approved local tech centre
22	System Error	Internal fault
		<ul style="list-style-type: none"> • Contact Autoflame approved local tech centre
23	Flash Data Error	Internal fault
		<ul style="list-style-type: none"> • Re-install software SD card
24	Processor Temperature Error	Internal fault
		<ul style="list-style-type: none"> • Check ambient temperature of unit does not exceed maximum recommended temperature
25	Burner Control Comms Error	Internal fault
		<ul style="list-style-type: none"> • Contact Autoflame approved local Tech Centre
26	Burner Control Reset	Internal fault
		<ul style="list-style-type: none"> • Contact Autoflame approved local Tech Centre
27	Software Error	Internal fault
		<ul style="list-style-type: none"> • Contact Autoflame approved local Tech Centre
28	Zero-Crossing Detection Error	Internal fault
		<ul style="list-style-type: none"> • Check mains supply going to unit is within acceptable voltage range
29	Mains Input Detection Error	Mains input stuck on
		<ul style="list-style-type: none"> • Check wiring and voltages on terminals 89 - 92
30	Channel 5 VSD Error	Feedback incorrect
		<ul style="list-style-type: none"> • Check VSD feedback against commissioned VSD and ensure the feedback is stable
31	Channel 6 VSD Error	Feedback incorrect
		<ul style="list-style-type: none"> • Check VSD feedback against commissioned VSD and ensure the feedback is stable

4 Errors and Lockouts

Error	Message	Description
32	VSD Feedback Change Too Small	Feedback change detected during commissioning is too small
		<ul style="list-style-type: none"> • Check VSD feedback during commissioning • Check option 99 for VSD on channel 5 and option 109 for VSD on channel 6 • Check wiring on terminals 1 - 3, 4 - 6, 10 - 12 and 13 - 15
33	Missing Commissioning Data	Internal fault
		<ul style="list-style-type: none"> • Check there is commissioning data for all options servomotors/VSD
34	FAR Execution Speed	Internal fault
		<ul style="list-style-type: none"> • Contact Autoflame approved local Tech Centre
35	Software Error	Internal fault
		<ul style="list-style-type: none"> • Contact Autoflame approved local Tech Centre
36	Software Error	Internal fault
		<ul style="list-style-type: none"> • Contact Autoflame approved local Tech Centre
37	Software Error	Internal fault
		<ul style="list-style-type: none"> • Contact Autoflame approved local Tech Centre
38	Software Error	Internal fault
		<ul style="list-style-type: none"> • Contact Autoflame approved local Tech Centre
39	VSD Sampling Error	VSD feedback current/ voltage too high on channel 5/6
		<ul style="list-style-type: none"> • Check wiring on terminals 1 - 3, 4 - 6, 10 - 12 and 13 - 15
40	VSD Feedback Too Low	VSD feedback value is too low during commissioning on channel 5/6
		<ul style="list-style-type: none"> • Check VSD feedback while commissioning
41	APS Commission Data Fault	No air pressure trim data for a point with EGA trim
		<ul style="list-style-type: none"> • Check EGA trim and air pressure trim in fuel-air curve
42	Comm VPS Gas Pressure Low	Commissioned gas pressure during VPS below option/ parameter 133 threshold
		<ul style="list-style-type: none"> • Check option/ parameter 133 and check gas pressure • Re-commission gas pressure sensor
43	Comm Running Gas Pressure Low	Commissioned gas pressure during running below option/ parameter 136
		<ul style="list-style-type: none"> • Check option/ parameter 136 and check gas pressure • Re-commission gas pressure sensor
44	Comm Air Pressure Low	Commissioned air pressure during running below option/ parameter s 147 and 149
		<ul style="list-style-type: none"> • Check option/parameters 147 and 149 • Re-commission air pressure sensor
45	Software Error	Internal fault
		<ul style="list-style-type: none"> • Contact Autoflame approved local tech centre
46	Software Error	Internal fault
		<ul style="list-style-type: none"> • Contact Autoflame approved local tech centre
47	Expansion PF Output (Check F5)	Internal fault
		<ul style="list-style-type: none"> • Check wiring on terminal PF • Check fuse 5 (2A) on expansion board
48	WL Alarm Output Internal Fault	Internal fault
		<ul style="list-style-type: none"> • Check expansion option 5 • Check wiring and voltages on terminals HAI, 1AI, 2AI

4 Errors and Lockouts

Error	Message	Description
49	Expansion Servo Hardware Fault	Internal fault
	<ul style="list-style-type: none"> Contact Autoflame approved local tech centre 	
50	Triac Power Supply Error (Check F2)	Internal fault
	<ul style="list-style-type: none"> Check wiring on terminal 69 Check fuse 2 (2A T) 	
51	Fused 12V Supply Error (Check F4)	Internal fault
	<ul style="list-style-type: none"> Check gas/air pressure sensor wiring on terminals 31 - 34, and load detector on 37 - 39 Check fuse 4 (500mA) 	
52	Fused 13.5V Supply Error (Check F3)	Internal fault
	<ul style="list-style-type: none"> Check IR scanner wiring on terminals 29, 30, 48, 49 and oil pressure sensor on 48, 49 Check fuse 3 (500mA) 	
53	Air Pressure Zeroing Fault	Commissioned air zero pressure is more than 5mbar from sensor's zero value
	<ul style="list-style-type: none"> Check air pressure sensor value during VPS 	
54	Software error	Internal fault
	<ul style="list-style-type: none"> Contact Autoflame approved local Tech Centre 	
55	Software error	Internal fault
	<ul style="list-style-type: none"> Contact Autoflame approved local Tech Centre 	
56	Software error	Internal fault
	<ul style="list-style-type: none"> Contact Autoflame approved local Tech Centre 	
57	Software error	Internal fault
	<ul style="list-style-type: none"> Contact Autoflame approved local Tech Centre 	
58	Software error	Internal fault
	<ul style="list-style-type: none"> Contact Autoflame approved local Tech Centre 	
59	Software error	Internal fault
	<ul style="list-style-type: none"> Contact Autoflame approved local Tech Centre 	
60	Software error	Internal fault
	<ul style="list-style-type: none"> Contact Autoflame approved local Tech Centre 	
61	Software error	Internal fault
	<ul style="list-style-type: none"> Contact Autoflame approved local Tech Centre 	
62	Software error	Internal fault
	<ul style="list-style-type: none"> Contact Autoflame approved local Tech Centre 	
63	Software error	Internal fault
	<ul style="list-style-type: none"> Contact Autoflame approved local Tech Centre 	
64	ADC Reference Voltage Error	Hardware fault
	<ul style="list-style-type: none"> Contact Autoflame approved local Tech Centre Contact Autoflame approved local Tech Centre 	
65	Software error	Internal fault
	<ul style="list-style-type: none"> Contact Autoflame approved local Tech Centre 	
66	Software error	Internal fault
	<ul style="list-style-type: none"> Contact Autoflame approved local Tech Centre 	
67	Software error	Internal fault
	<ul style="list-style-type: none"> Contact Autoflame approved local Tech Centre 	

4.2 Lockouts

Lockouts occur when the MM detects a fault with the burner operation such as VPS, gas/air pressure sensor and flame scanners. The lockout must be cleared and investigated on the MM.

Lockout	Message	Description
1	CPI Input Wrong State	Proof of closure switch opened during ignition sequence
		<ul style="list-style-type: none"> • Check wiring on terminal 55 • Check proof of closure switches
2	No Air Proving	No air pressure during start/ firing
		<ul style="list-style-type: none"> • Check wiring on terminal 54 • Check air pressure switch • Check air pressure sensor • Check air pressures during running
3	Ignition Output Fault	Voltage detected when output is off (and vice versa)
		<ul style="list-style-type: none"> • Check wiring and voltage on terminal 63
4	Motor Output Fault	Voltage detected when output is off (and vice versa)
		<ul style="list-style-type: none"> • Check wiring and voltage on terminal 58
5	Start Gas Output Fault	Voltage detected when output is off (and vice versa)
		<ul style="list-style-type: none"> • Check wiring and voltage on terminal 59
6	Main Gas 1 Output Fault	Voltage detected when output is off (and vice versa)
		<ul style="list-style-type: none"> • Check wiring and voltage on terminal 60
7	Main Gas 2 Output Fault	Voltage detected when output is off (and vice versa)
		<ul style="list-style-type: none"> • Check wiring and voltage on terminal 61
8	Vent Valve Output Fault	Voltage detected when output is off (and vice versa)
		<ul style="list-style-type: none"> • Check wiring and voltage on terminal 62
9	Failsafe Relay (Check F1)	Voltage detected when output is off (and vice versa)
		<ul style="list-style-type: none"> • Check wiring and voltage on terminal 57 • Check fuse 1 (6.3A T) and wiring on terminals 50 - 64
10	Simulated Flame	Flame is present when it not should be
		<ul style="list-style-type: none"> • Isolate gas/ oil immediately • Call a certified Commissioning Engineer to investigate • If this lockout occurs during shutdown a post-purge may be required for after burn
11	VPS Air Proving Fail	Leak detected during 'air proving' part of VPS
		<ul style="list-style-type: none"> • Check 1st main valve • Call a certified Commissioning Engineer to investigate
12	VPS Gas Proving Fail	Leak detected during 'gas proving' part of VPS
		<ul style="list-style-type: none"> • Check option/parameter 133 • Check 2nd main gas valve and vent valve • Check pilot valve if using single valve pilot • Isolate gas and call a certified Commissioning Engineer to investigate
13	No Flame Signal	No flame detected during ignition/ firing
		<ul style="list-style-type: none"> • Visually check flame • Check the flame scanner • Call a certified Commissioning Engineer to investigate
14	Shutter Fault	UV signal detected during shutter operation on self-check
		<ul style="list-style-type: none"> • Check wiring on terminals 21 and 22 • Check UV scanner type and check option/ parameter 110 is set accordingly

4 Errors and Lockouts

Lockout	Message	Description
15	NO CPI Reset	Proof of closure switch not made after valves closed
		<ul style="list-style-type: none"> • Check wiring on terminal 55 and check proof of closure switches
16	Prolonged Lockout Reset	Prolonged voltage detected on terminal 56/ lockout reset button permanently pressed
		<ul style="list-style-type: none"> • Check lockout reset button is not pressed • Check wiring on terminal 56
17	Gas Pressure Low	Gas pressure low limit exceeded while firing(gas sensor)
		<ul style="list-style-type: none"> • Check gas pressure • Check option/ parameter 136
18	Gas Pressure High	Gas pressure high limit exceeded while firing (gas sensor)
		<ul style="list-style-type: none"> • Check gas pressure • Check option/ parameter 137
19	RAM Test Failed	Hardware fault
		<ul style="list-style-type: none"> • Contact Autoflame approved local tech centre
20	PROM Test Failed	Hardware fault
		<ul style="list-style-type: none"> • Contact Autoflame approved local tech centre
21	FSR Test 1A	Internal relay test failed
		<ul style="list-style-type: none"> • Check wiring and voltages on terminals 50 - 63
22	FSR Test 2A	Internal relay test failed
		<ul style="list-style-type: none"> • Check wiring and voltages on terminals 50 - 63
23	FSR Test 1B	Internal relay test failed
		<ul style="list-style-type: none"> • Check wiring and voltages on terminals 50 - 63
24	FSR Test 2B	Internal relay test failed
		<ul style="list-style-type: none"> • Check wiring and voltages on terminals 50 - 63
25	Watchdog Fail 2A	Internal check failed
		<ul style="list-style-type: none"> • Contact Autoflame approved local tech centre
26	Watchdog Fail 2B	Internal check failed
		<ul style="list-style-type: none"> • Contact Autoflame approved local tech centre
27	Watchdog Fail 2C	Internal check failed
		<ul style="list-style-type: none"> • Contact Autoflame approved local tech centre
28	Watchdog Fail 2D	Internal check failed
		<ul style="list-style-type: none"> • Contact Autoflame
29	Input Fault	Power supply fault
		<ul style="list-style-type: none"> • Check mains voltage to the MM
32	Gas Pressure Low Limit	Gas pressure lower than commissioned VPS value
		<ul style="list-style-type: none"> • Check gas pressure sensor value • Check option/parameter 136
33	VPS Air Zeroing	Gas pressure sensor cannot be zeroed at VPS venting
		<ul style="list-style-type: none"> • Check gas pressure is within zero range (see MM Application Possibilities) • Check vent valve
36	Oil Pressure Too Low	Oil pressure below offset lower limit during running
		<ul style="list-style-type: none"> • Check option/parameter 139 • Check oil pressure sensor
37	Oil Pressure Too High	Oil pressure above offset upper limit during running
		<ul style="list-style-type: none"> • Check option/parameter 140 • Check oil pressure sensor

4 Errors and Lockouts

Lockout	Message	Description
39	Freeze Timeout	MM kept in Phase Hold for more than 10minutes
		<ul style="list-style-type: none"> MM kept in Phase Hold during commissioning for more than 10 minutes
40	Purge Air Pressure Low	Insufficient air pressure during purge
		<ul style="list-style-type: none"> Check option/parameter 141 Check air pressure sensor/ air pressure switch
42	Terminal 86 Inverse	Input detected on both terminals 85,86 where there should not be, and vice versa
		<ul style="list-style-type: none"> Check option/parameter 122 Check wiring and voltages on terminals 85, 86
43	Terminal 85/86 Fault	Hardware fault on terminals 85/86
		<ul style="list-style-type: none"> Check wiring and voltages on terminals 85, 86 and contact Autoflame
44	Proving Circuit Fail T52	Loss of input on terminal 52; MM must see input at all times from position to purge to post purge
		<ul style="list-style-type: none"> Check wiring on terminal 52
45	No Proving Circuit Set	Secondary proving timeout elapsed
		<ul style="list-style-type: none"> Check option/parameter 157 Check wiring on terminal 52
46	Proving Interlock Timeout	Purge interlock timeout elapsed
		<ul style="list-style-type: none"> Check option/ parameters 155 and 158 Check wiring on terminal 81
52	High IR Ambient	Flame detected when there should not be
		<ul style="list-style-type: none"> Visually check flame and check IR scanner Call a certified Commissioning Engineer to investigate
53	IR Comms Lost	Loss of comms with IR scanner
		<ul style="list-style-type: none"> Check wiring and screen on terminals 29, 30, 48 and 49 Check that the IR scanner is not removed from the magnetic ring socket
54	Watchdog Long X A	Internal check failed
		<ul style="list-style-type: none"> Contact Autoflame approved local tech centre
55	Watchdog Long Y A	Internal check failed
		<ul style="list-style-type: none"> Contact Autoflame approved local tech centre
56	Watchdog Off A	Internal check failed
		<ul style="list-style-type: none"> Contact Autoflame approved local tech centre
57	Watchdog Short X B	Internal check failed
		<ul style="list-style-type: none"> Contact Autoflame approved local tech centre
58	Watchdog Short Y B	Internal check failed
		<ul style="list-style-type: none"> Contact Autoflame approved local tech centre
59	Watchdog Long X B	Internal check failed
		<ul style="list-style-type: none"> Contact Autoflame approved local tech centre
60	Watchdog Long Y B	Internal check failed
		<ul style="list-style-type: none"> Contact Autoflame approved local tech centre
61	Watchdog Off B	Internal check failed
		<ul style="list-style-type: none"> Contact Autoflame approved local tech centre
62	UV Signal Too High	Internal check failed for UV
		<ul style="list-style-type: none"> Check wiring on terminals 21, 22, 50 and 51

4 Errors and Lockouts

Lockout	Message	Description
63	Purge Limit Switch	Interlock not made on terminal 81
		<ul style="list-style-type: none"> • Check option/ parameter 155 • Check wiring on terminal 81
64	Start Limit Switch	Interlock not made on terminal 80
		<ul style="list-style-type: none"> • Check option/ parameter 154 • Check wiring on terminal 80
65	FSR A	Internal check failed
		<ul style="list-style-type: none"> • Check wiring and voltages on terminals 50 - 63
66	FSR B	Internal check failed
		<ul style="list-style-type: none"> • Check wiring and voltages on terminals 50 - 63
67	Gas Sensor Comms	Signal lost from gas pressure sensor
		<ul style="list-style-type: none"> • Check wiring and screen on terminals 31 - 34
68	Gas Sensor Type	Internal fault
		<ul style="list-style-type: none"> • Contact Autoflame approved local tech centre
69	Gas Sensor Fault	Internal pressure sensor fault
		<ul style="list-style-type: none"> • Contact Autoflame approved local tech centre
70	UV Pot Fault	Internal UV scanner fault
		<ul style="list-style-type: none"> • Contact Autoflame approved local tech centre
71	Air Sensor Comms	Signal lost from air pressure sensor
		<ul style="list-style-type: none"> • Check wiring and screen on terminals 31 - 34
72	Air Sensor Type	Internal fault
		<ul style="list-style-type: none"> • Contact Autoflame approved local tech centre
73	Air Sensor Fault	Internal pressure sensor fault
		<ul style="list-style-type: none"> • Contact Autoflame approved local tech centre
74	Air Sensor Zero	Air pressure is more than 5mbar from sensor's zero value
		<ul style="list-style-type: none"> • Check air pressure sensor value during VPS
75	Air Sensor Signal High	Air pressure is above 400mbar
		<ul style="list-style-type: none"> • Check Autoflame approved local tech centre
76	Air Sensor Error Window	Air pressure outside of these limits for 3 seconds
		<ul style="list-style-type: none"> • Check air pressure • Check option/parameter 147
77	Wait Air Switch Timeout	Voltage has not been reset for 2minutes
		<ul style="list-style-type: none"> • Check air pressure sensor value during VPS • Check voltage has been reset on terminal 54 within 2minutes before run to purge • Check wiring and voltage on terminal 54
78	Gas Proving Fail High	Gas pressure too high during VPS
		<ul style="list-style-type: none"> • Isolate gas • Check 1" main valve and vent valve • Check option/ parameters 133 and 134 • Call a certified Commissioning Engineer to investigate
79	FSR Test 1C	Hardware fault
		<ul style="list-style-type: none"> • Contact Autoflame approved local tech centre
80	Timeout on Reaching Purge	Time set in option/parameter 124 has elapsed
		<ul style="list-style-type: none"> • Check option/parameter 124
81	Oil Pressure Sensor Fault	No comms received from oil pressure sensor
		<ul style="list-style-type: none"> • Check wiring and screen on terminals 48, 49

4 Errors and Lockouts

Lockout	Message	Description
82	Purge Pressure Proving Input	Input on T81 read high during relay test phases
		<ul style="list-style-type: none"> • Input has been made before the blower starts; it should only be made continuously during purge. • Check wiring on terminal 81.
198	BC Input Short	Internal fault
		<ul style="list-style-type: none"> • Contact Autoflame approved local tech centre
199	Lockout 199	Internal fault
		<ul style="list-style-type: none"> • Contact Autoflame approved local tech centre
200	Lockout Cleared	Lockout has been cleared
		<ul style="list-style-type: none"> • MM status after lockout has been reset (Modbus)
201	Power up CPU Test Fail	Internal check failed
		<ul style="list-style-type: none"> • Contact Autoflame approved local tech centre
202	Power up EEPROM Test Fail	Internal check failed
		<ul style="list-style-type: none"> • Contact Autoflame approved local tech centre

4.3 Alarms and Warnings

Alarms and warnings are faults detected with the system operation. If an alarm occurs, the burner will stop running, and if a warning occurs, the burner will continue to run. The following options/parameters set whether system operation faults are set as alarms or warnings:

Option 13	EGA Fault Response
Option 14	Warning Response
Expansion Option 9	Burner Operation at High Water
Expansion Option 20	Burner Operation on Feed water Control Fault
Expansion Option 88	Action on Pressure Sensor Fault

Fault	Message	Description
1	EGA Internal Error	Fault on EGA
		<ul style="list-style-type: none"> Alarm or warning depending on option 13 Check EGA for fault description
2	No EGA Communications	MM has lost communications with EGA
		<ul style="list-style-type: none"> Alarm or warning based on option 13 (warning if option 12 is set to monitoring only) Check parameter 10 is set to correct EGA version Check EGA operating mode is selected as 'EGA with MM' Check wiring between EGA and MM (terminals 25 and 26 on MM)
3	O ₂ Upper Limit	O ₂ value is above upper limit offset of commissioned value*
		<ul style="list-style-type: none"> Alarm or warning depending on option 13 Check exhaust gas readings and option 19
4	O ₂ Absolute Limit	O ₂ value is below absolute limit*
		<ul style="list-style-type: none"> Alarm or warning depending on option 13 Check exhaust gas readings and option 25
5	O ₂ Lower Limit	O ₂ value is below lower limit offset of commissioned value*
		<ul style="list-style-type: none"> Alarm or warning depending on option 13 Check exhaust gas readings and option 22
6	CO ₂ Upper Limit	CO ₂ value is above upper limit offset of commissioned value*
		<ul style="list-style-type: none"> Alarm or warning depending on option 13 Check exhaust gas readings and option 20
7	CO ₂ Absolute Limit	CO ₂ value is above absolute limit*
		<ul style="list-style-type: none"> Alarm or warning depending on option 13 Check exhaust gas readings and option 26
8	CO ₂ Lower Limit	CO ₂ value is below lower limit offset of commissioned value*
		<ul style="list-style-type: none"> Alarm or warning depending on option 13 Check exhaust gas readings and option 23
9	CO Upper Limit	CO value is above upper limit offset of commissioned value*
		<ul style="list-style-type: none"> Alarm or warning depending on option 13 Check exhaust gas readings and option 21
10	CO Absolute Limit	CO value is above absolute limit*
		<ul style="list-style-type: none"> Alarm or warning depending on option 13 Check exhaust gas readings and option 27
11	NO Upper Limit	NO value is above upper limit offset of commissioned value*
		<ul style="list-style-type: none"> Alarm or warning depending on option 13 Check exhaust gas readings and parameter 94

4 Errors and Lockouts

Fault	Message	Description
12	Exhaust Temperature Upper Limit	Exhaust temperature is above upper limit offset of commissioned value*
		<ul style="list-style-type: none"> • Alarm or warning depending on option 13 • Check exhaust gas readings and parameter 96
13	Exhaust Temperature Absolute Limit	Exhaust temperature is above absolute limit*
		<ul style="list-style-type: none"> • Alarm or warning depending on option 13 • Check exhaust gas readings and parameter 97
50	Load Sensor Fault	Incorrect/no load sensor detected
		<ul style="list-style-type: none"> • Alarm • Check option 1 • Check wiring on terminals 37 - 39
51	Auxiliary Input Low	3mA or lower received from 4-20mA external modulation/ external setpoint
		<ul style="list-style-type: none"> • Alarm • Check parameter 69 • Check feedback from external modulation/ external setpoint controller • Check wiring on terminals 7 - 9
80	Oil Pressure Sensor Fault	No comms received from oil pressure sensor
		<ul style="list-style-type: none"> • Warning (lockout 81 if oil pressure limits set in option/parameters 139 and 140) • Check wiring and screen on terminals 48, 49
100	Cap Probe 1 Communications Fault	No comms with capacitance probe 1
		<ul style="list-style-type: none"> • Alarm • Check wiring and screen on terminals 1P+, 1P-, 1T+ and 1T-
101	Cap Probe 2 Communications Fault	No comms with capacitance probe 2
		<ul style="list-style-type: none"> • Alarm • Check wiring and screen on terminals 2P+, 2P-, 2T+ and 2T-
102	Cap Probe 1 Short Circuit	Hz reading is below 10kHz
		<ul style="list-style-type: none"> • Alarm • Check water level Hz reading • Check wiring on terminals 1P+, 1P-, 1T+ and 1T-
103	Cap Probe 2 Short Circuit	Hz reading is below 10kHz
		<ul style="list-style-type: none"> • Alarm • Check water level Hz reading • Check wiring on terminals 2P+, 2P-, 2T+ and 2T-
104	Cap Probe 1 Temp Compensation Error	Temperature corrected probe reference is not as expected
		<ul style="list-style-type: none"> • Alarm • Re-commission capacitance probes at temperature
105	Cap Probe 2 Temp Compensation Error	Temperature corrected probe reference is not as expected
		<ul style="list-style-type: none"> • Alarm • Re-commission capacitance probes at temperature
106	Cap Probe 1 Still Water Detected	Wave signature high to low peak distance is less than still water threshold
		<ul style="list-style-type: none"> • Alarm • Check still water threshold in expansion option 28 • Check capacitance probe 1 reading history

4 Errors and Lockouts

Fault	Message	Description
107	Cap Probe 2 Still Water Detected	Wave signature high to low peak distance is less than still water threshold
		<ul style="list-style-type: none"> • Alarm • Check still water threshold in expansion option 28 • Check capacitance probe 2 reading history
108	Cap Probe 1 Serial Number Mismatch	Probe serial number detected is not the commissioned probe serial number
		<ul style="list-style-type: none"> • Alarm • If changing capacitance probe 1, re-commission is required
109	Cap Probe 2 Serial Number Mismatch	Probe serial number detected is not the commissioned probe serial number
		<ul style="list-style-type: none"> • Alarm • If changing capacitance probe 2, re-commission is required
110	Cap Probe 1 Detected But Not Optioned	Probe connected but not optioned
		<ul style="list-style-type: none"> • Alarm • Check expansion options 1 and 3 • Check wiring on terminals 1P+, 1P-, 1T+ and 1T-
111	Cap Probe 2 Detected But Not Optioned	Probe connected but not optioned
		<ul style="list-style-type: none"> • Alarm • Check expansion options 1 and 3 • Check wiring on terminals 2P+, 2P-, 2T+ and 2T-
112	External Level Sensor Input Low	3mA or lower received from 4-20mA external level sensor
		<ul style="list-style-type: none"> • Alarm • Check feedback from external level sensor • Check wiring on terminals EX- and EX+
113	Probe Reading Mismatch	Difference between probes/sensor readings is below mismatch threshold
		<ul style="list-style-type: none"> • Alarm • Check expansion option 27 • Check capacitance probes and sensor readings
114	Probe Serial Numbers are the Same	One capacitance probe detected on both capacitance probe terminals
		<ul style="list-style-type: none"> • Alarm • If using two capacitance probes, then two individual probes must be connected • Check wiring on terminals 1P+, 1P-, 1T+, 1T-, 2P+, 2P-, 2T+ and 2T-
120	Aux WL Inputs Mismatch	High water and 1 st or 2 nd low auxiliary level inputs detected simultaneously
		<ul style="list-style-type: none"> • Alarm • Check wiring on terminals HAI, 1AI and 2AI
121	Water Levels Diverse	Probes/ sensor detects 1 st or 2 nd low and high water simultaneously
		<ul style="list-style-type: none"> • Alarm • Check water level readings for probes and sensor if optioned • Re-commission probes/sensor
122	Permanent Alarm Reset Input	Input held on alarm reset terminal for more than 10 seconds
		<ul style="list-style-type: none"> • Alarm • Check input on terminal M/R

4 Errors and Lockouts

Fault	Message	Description	Type
123	Second Low Probe Communications Fault	No comms with second low probe	
		<ul style="list-style-type: none"> • Alarm • Check wiring and screen on terminals 5T+, 5T-, 4P- and 4P+ 	
124	Second Low Probe Hardware Fault	Internal check failed	
		<ul style="list-style-type: none"> • Alarm • Contact Autoflame approved local tech centre 	
125	Permanent Test Input	Input held on test terminal for more than 60 seconds	
		<ul style="list-style-type: none"> • Alarm • Check input on terminal TST 	
126	Second Low Probe Detected But Not Optioned	Second low probe connected but not optioned	
		<ul style="list-style-type: none"> • Alarm • Check expansion option 6 • Check wiring on terminals 5T+, 5T-, 4P- and 4P+ 	
127	Aux WL Inputs Detect But Not Optioned	Mains detected on auxiliary WL inputs but not optioned	
		<ul style="list-style-type: none"> • Alarm • Check expansion option 5 • Check wiring on terminals HAI, 1AI and 2AI 	
130	Feed Water Servo Position Error	Servomotor is outside of the commissioned range	
		<ul style="list-style-type: none"> • Alarm or warning or depending on expansion option 20 • Check wiring on terminals P-, FW and P+ • Check signal cable form the MM to the servomotor is screened at one end • Check that the servomotor is zeroed correctly 	
131	Feed Water Servo Movement Error	Servomotor moves when not expected and vice versa	
		<ul style="list-style-type: none"> • Alarm or warning depending on expansion option 20 • Check wiring and voltages on terminals MVI and MVD • Check servomotor drives in correct direction • Check feed water valve is not stuck 	
150	High Water	Probes/sensor detect water level above commissioned high water	
		<ul style="list-style-type: none"> • Alarm or warning depending on expansion option 9 • Check water level reading 	
151	Pre-High Water	Probes/sensor detect water level above set pre-high water	
		<ul style="list-style-type: none"> • Warning • Check water level reading • Check expansion option 7 	
152	Pre-1" Low	Probes/sensor detect water level below set pre-1" low	
		<ul style="list-style-type: none"> • Warning • Check water level reading • Check expansion option 8 	
153	1" Low	Probes/sensor detect water level below commissioned 1" low	
		<ul style="list-style-type: none"> • Alarm • Check water level reading • 1" low alarm will automatically clear if water level increases above 1" low 	

4 Errors and Lockouts

Fault	Message	Description
154	2 nd Low	Probes/sensor detect water level below 2 nd low
		<ul style="list-style-type: none"> • Alarm • Check water level reading • 2nd low alarm requires manual reset
155	Shunt Switch Time Expired	Once shunt switch time expires, system goes to normally running
		<ul style="list-style-type: none"> • Warning • If water drops after shunt switch time expires, system will generate 1st or 2nd low as relevant
200	Top Blowdown Sensor Communications Fault	No comms with the top blowdown sensor
		<ul style="list-style-type: none"> • Warning • Check wiring and screen on terminals 3P+, 3P-, 3T+ and 3T-
201	Top Blowdown Servo Position Error	Servomotor is outside of the commissioned range
		<ul style="list-style-type: none"> • Warning • Check wiring on terminals P-, TW, P+ and TBI, TBD • Check signal cable form the MM to the servomotor is screened at one end • Check that the servomotor is zeroed correctly
202	Top Blowdown Servo Movement Error	Servomotor moves when not expected and vice versa
		<ul style="list-style-type: none"> • Warning • Check wiring on terminals TBI and TBD • Check servomotor drives in correct direction • Check top blowdown valve is not stuck
250	Top Blowdown Reading High	TDS value detected too high
		<ul style="list-style-type: none"> • Warning • Check expansion option 46 and TDS value
300	Bottom Blowdown Controller Comms	No comms with bottom blowdown controller
		<ul style="list-style-type: none"> • Warning • Check bottom blowdown controller is powered on and enabled • Check wiring and screen on terminals 5T+ and 5T-
301	Bottom Blowdown Controller Software Fault	Internal check failed
		<ul style="list-style-type: none"> • Warning • Contact Autoflame approved local tech centre
302	Bottom Blowdown Servo Closing Fault	No movement detected when bottom blowdown valve goes to close
		<ul style="list-style-type: none"> • Warning • Check wiring on terminals 5T+ and 5T- • Check bottom blowdown valve is not stuck
303	Bottom Blowdown Servo Opening Fault	No movement detected when bottom blowdown valve goes to open
		<ul style="list-style-type: none"> • Warning • Check wiring on terminals 5T+ and 5T- • Check bottom blowdown valve is not stuck
304	Bottom Blowdown Servo Battery Drive Fault	Battery has failed on bottom blowdown controller
		<ul style="list-style-type: none"> • Warning • Contact Autoflame approved local tech centre

4 Errors and Lockouts

Fault	Message	Description
305	Bottom Blowdown Controller Main Power Fault	Main power has failed on bottom blowdown controller
		<ul style="list-style-type: none"> • Warning • Contact Autoflame approved local tech centre
350	Bottom Blowdown Servo Not Commissioned	Bottom blowdown controller has not been requested to drive servomotor to closed since it was powered on
		<ul style="list-style-type: none"> • Warning • Commission bottom blowdown servomotor
400	Draught Pressure Sensor Timeout	No comms within 2 seconds from draught pressure sensor
		<ul style="list-style-type: none"> • Alarm or warning depending on option 88 • Check wiring and screen on terminals DT+, DT-, DP- and DP+
410	Draught Pressure Outside Tolerance	Pressure is outside of set tolerance
		<ul style="list-style-type: none"> • Alarm or warning depending on option 88 • Check expansion option 87
420	Fuel flow Feedback Input Low	3mA or lower received from 4-20mA external fuel flow input
		<ul style="list-style-type: none"> • Warning • Check feedback from external fuel flow input • Check wiring on terminals EX- and EX+
430	Fuel flow Feedback Below Tolerance	Fuel flow signal below fuel flow feedback fault tolerance
		<ul style="list-style-type: none"> • Warning • Check feedback from external fuel flow input • Check option 60
431	Fuel flow Feedback Above Tolerance	Fuel flow signal above fuel flow feedback fault tolerance
		<ul style="list-style-type: none"> • Warning • Check feedback from external fuel flow input • Check option 60
440	Temperature Sensor T1 Fault	Fault or no comms with T1 sensor
		<ul style="list-style-type: none"> • Warning • Check wiring and screen on terminals - and T1
441	Temperature Sensor T2 Fault	Fault or no comms with T2 sensor
		<ul style="list-style-type: none"> • Warning • Check wiring and screen on terminals - and T2
442	Temperature Sensor T3 Fault	Fault or no comms with T3 sensor
		<ul style="list-style-type: none"> • Warning • Check wiring and screen on terminals - and T3
443	Make Up Flow Meter Fault	Fault or no comms with make up flow meter
		<ul style="list-style-type: none"> • Warning • Check wiring and screen on terminals F- and MF
444	Condensate Flow Meter Fault	Fault or no comms with condensate flow meter
		<ul style="list-style-type: none"> • Warning • Check wiring and screen on terminals F- and CF
445	Deaerator IO Comms Fault	Fault or no comms with deaerator IO
		<ul style="list-style-type: none"> • Warning • Check wiring and screen on terminals 6T+ and 6T-

4 Errors and Lockouts

Fault	Message	Description
500	Multi-Burner Communications Fault	Loss of comms between MMs in multi-burner loop
		<ul style="list-style-type: none"> • Alarm • Check wiring on terminals 23 and 24 on all MMs in multi-burner loop
501	Multi-Burner Version Mismatch	Software versions of MMs in multi-burner loop do not match
		<ul style="list-style-type: none"> • Alarm • Check that software versions of MMs in multi-burner loop match
502	Multi-Burner Not Polled	MM in multi-burner loop has been detected but not polled
		<ul style="list-style-type: none"> • Alarm • Check option 51 on master MM • Check wiring on terminals 23 and 24
503	Multi-Burner Config (Multi-Burner Mode)	Multi-burner mode is not the same for all MMs in loop
		<ul style="list-style-type: none"> • Alarm • Check option 43 on all MMs in multi-burner loop
504	Multi-Burner Config (Fuel Index)	Same fuel number must be selected on all MMs in multi-burner loop
		<ul style="list-style-type: none"> • Alarm • Check which fuel is selected on all MMs in multi-burner loop • Check wiring on terminals 89, 90, 91 and 92
505	Multi-Burner Config (Fuel Type)	Fuel type is not the same for all MMs in multi-burner loop
		<ul style="list-style-type: none"> • Alarm • Check option/parameters 150 - 153 on all MMs in multi-burner loop
506	Multi-Burner Config (Pilot Type)	Pilot type not the same for all MMs multi-burner loop
		<ul style="list-style-type: none"> • Alarm • Check option/parameter 111 on all MMs in multi-burner loop
507	Multi-Burner Config (Load Sensor)	Load sensor not set the same for all MMs in multi-burner loop
		<ul style="list-style-type: none"> • Alarm • Check option 1 on all MMs in multi-burner loop
550	Fuel Flow Meter Fault	Less than 3mA signal received from fuel flow meter
		<ul style="list-style-type: none"> • Alarm or warning depending on expansion option 152 (if set to warning, the MM will use the commissioned value without any fuel or air servomotor adjustment) • Check wiring and screen on terminal MF and F-
551	Air Flow Meter Fault	Less than 3mA signal received from air flow meter
		<ul style="list-style-type: none"> • Alarm or warning depending on expansion option 152 (if set to warning, the MM will use the commissioned value without any fuel or air servomotor adjustment) • Check wiring and screen on terminal EX+ and EX-
552	Fuel Temperature Sensor Fault (T2)	Fault or no comms with T2 sensor
		<ul style="list-style-type: none"> • Warning (MM will use commissioned temperature) • Check wiring and screen on terminals - and T2
553	Air Temp Sensor Fault (T3)	Fault or no comms with T3 sensor
		<ul style="list-style-type: none"> • Warning (MM will use commissioned temperature) • Check wiring and screen on terminals - and T3

4 Errors and Lockouts

Fault	Message	Description	
554	Fuel Pressure Sensor Fault	Fault or no comms with fuel pressure sensor	
	<ul style="list-style-type: none"> • Warning or lockout if VPS and/or pressure limits enabled in option/parameters 125 - 128 (if warning, MM uses commissioned pressure) • Check wiring and screen on terminals 31 - 34 		
555	Air Pressure Sensor Fault	Fault or no comms with air pressure sensor	Warning/Lockout - option 148
	<ul style="list-style-type: none"> • • Check wiring and screen on terminals 31 - 34 • Lockout if option 148 is set for air pressure sensor in flame safeguard 		
560	Fully Metered Air Adjustment Failure	Air adjustment has reached limit and fuel-air ratio still not met	Alarm/Warning - exp option 151
	<ul style="list-style-type: none"> • Check for changes affecting combustion including fuel/air pressure, temperature etc. • Warning if expansion option 151 is set to 1 • Warning and air adjustment is disabled if expansion option 151 is set to 2 		
580	Servo Control I/O Unit Communications Fault	Fault or no comms with the servo control IO module	Alarm
	<ul style="list-style-type: none"> • Check for wiring on terminals 6T+ and 6T- 		
581	Servo Control I/O Unit Channel 1 Output Fault	4-20mA output detects open circuit	Alarm
	<ul style="list-style-type: none"> • Check wiring on output 1 on I/O module 		
582	Servo Control I/O Unit Channel 2 Output Fault	4-20mA output detects open circuit	Alarm
	<ul style="list-style-type: none"> • Check wiring on output 2 on I/O module 		
583	Servo Control I/O Unit Channel 3 Output Fault	4-20mA output detects open circuit	Alarm
	<ul style="list-style-type: none"> • Check wiring on output 3 on I/O module 		
584	Servo Control I/O Unit Channel 4 Output Fault	4-20mA output detects open circuit	Alarm
	<ul style="list-style-type: none"> • Check wiring on output 4 on I/O module 		
585	Servo Control I/O Unit Channel 7 Output Fault	4-20mA output detects open circuit	Alarm
	<ul style="list-style-type: none"> • Check wiring on output 5 on I/O module 		
586	Servo Control I/O Unit Channel 1 Input Fault	4-20mA input less than 3mA	Alarm
	<ul style="list-style-type: none"> • Check wiring on input 1 on I/O module 		
587	Servo Control I/O Unit Channel 2 Input Fault	4-20mA input less than 3mA	Alarm
	<ul style="list-style-type: none"> • Check wiring on input 2 on I/O module 		
588	Servo Control I/O Unit Channel 3 Input Fault	4-20mA input less than 3mA	Alarm
	<ul style="list-style-type: none"> • Check wiring on input 3 on I/O module 		
589	Servo Control I/O Unit Channel 4 Input Fault	4-20mA input less than 3mA	Alarm
	<ul style="list-style-type: none"> • Check wiring on input 4 on I/O module 		
590	Servo Control I/O Unit Channel 7 Input Fault	4-20mA input less than 3mA	Alarm
	<ul style="list-style-type: none"> • Check wiring on input 5 on I/O module 		

*When option 12 is set to 3 for trim and combustion limits, the combustion limits are evaluated once per trim cycle. A combustion limit error will occur if the current exhaust value has crossed the combustion limit for the number of trim cycles set in parameter 17 (the default value is 3 cycles).

4.4 SettingsConflicts

Some of the options, parameters and expansion options may require another option, parameter or expansion option to be set. Please see the below table for these settings conflicts. A setting conflict will result in the MM being forced in to Commission mode.

Setting Conflict Message
(1) (P53, P54, P55, P56) External load sensor incorrectly configured
<ul style="list-style-type: none"> The external load sensor must be set with the minimum and maximum values and voltages. Check option 1 and parameters 53 – 56.
(1) (81, 83) OTC setpoints too high for optioned load sensor
<ul style="list-style-type: none"> If minimum and maximum setpoints OTC setpoints must be set within the possible range of the optioned load detector. Check option 1, 81 and 83.
(9) (45) Internal stat must be disabled if load sensor not present
<ul style="list-style-type: none"> If external modulation is enabled without a load sensor, the internal stat must always be closed. Check options 9 and 45.
(30) (31) Invalid remote setpoint configuration
<ul style="list-style-type: none"> The Minimum Remote Setpoint (DTI/Modbus/External) cannot be set higher than the Maximum Remote Setpoint (DTI/Modbus/External) and vice versa. Check options 30 and 31.
(43) (44) (E1) Water level control only be on the multi-burner master
<ul style="list-style-type: none"> Water level control should only be enabled on the master (multi-burner ID 1 set in option 44), when using the multi-burner function. Check options 43 ,44 and expansion option 1.
(43) (44) (16) Sequencing only be only the multi-burner master
<ul style="list-style-type: none"> Only the master (multi-burner ID 1 set in option 44) can be set for sequencing. Check options 16, 43 and 44.
(43) (44) (12) EGA and trim can only be on the multi-burner master
<ul style="list-style-type: none"> Only the master (multi-burner ID 1 set in option 44) can be optioned with an EGA. Check options 12, 43 and 44.
(43) (44) (E110) Firstouts can only be on the multi-burner master
<ul style="list-style-type: none"> Only the master (multi-burner ID 1 set in option 44) can have first outs enabled. Check options 43, 44 and expansion option 110.
(43) (44) (E120) Heat-flow can only be on the multi-burner master
<ul style="list-style-type: none"> Only the master (multi-burner ID 1 set in option 44) can have heat flow function enabled. Check options 43, 44 and expansion option 120.
(43) (44) (45) External modulation can only be on the multi-burner master
<ul style="list-style-type: none"> Only the master (multi-burner ID 1 set in option 4) can be set for external modulation. Check options 43 – 45.
(43) (44) (E82) Draught control can only be on the multi-burner master.
<ul style="list-style-type: none"> Only the master (multi-burner ID 1 set in option 4) can be set for draught control. Check options 43 and 44, and expansion option 82.
(43) (57) Fuel flow metering must be enabled for multi-burner
<ul style="list-style-type: none"> The multi-burner function requires fuel flow metering. Check options 43 and 57.
(43) (135) NFPA Post Purge cannot be optioned with multi-burner
<ul style="list-style-type: none"> The multi-burner function can only use standard, not NFA post purge. Check option 43 and option/parameter 135.

Setting Conflict Message
(45) (55) External modulation conflict
<ul style="list-style-type: none"> Switched T88 external modulation is not set with permanent external modulation. Check options 45 and 55.
(45/55) (16) External modulation conflict
<ul style="list-style-type: none"> External modulation cannot be used on any MMs in sequencing. Check options 16, 45 and 55
(45) (P72) External modulation and external setpoint both optioned
<ul style="list-style-type: none"> External modulation and external setpoint cannot be used simultaneously. Check option 45 and parameter 72.
(81, 82, 83, 84) OTC Configuration invalid
<ul style="list-style-type: none"> Setpoints at minimum and maximum outside temperatures cannot be set the same. Minimum and maximum outside temperatures cannot be set the same. Check options 81, 82, 83 and 84
(111) (122) Flame scanner changeover cannot be optioned with no pilot.
<ul style="list-style-type: none"> If no pilot is set, then flame scanner changeover cannot be used. Check option/parameters 111 and 122.
(111) (130) Single valve pilot cannot be optioned with no pilot.
<ul style="list-style-type: none"> If no pilot is set, then gas valve configuration cannot be set for single valve pilot. Check option/parameters 111 and 130.
(112, 135) (158) Purge pressure proving timeout shorter than pre-purge time.
<ul style="list-style-type: none"> Purge pressure proving timeout must be longer than the pre-purge time Check option/parameters 112, 135 and 158.
(118, 135) (158) Purge pressure proving timeout shorter than post-purge time.
<ul style="list-style-type: none"> Purge pressure proving timeout must be longer than the post-purge time Check option/parameters 118, 135 and 158.
(118) (135) NFPA Post Purge must be at least 15 seconds.
<ul style="list-style-type: none"> If NFPA Post Purge is enabled, then this time must be set to a minimum of 15 seconds. Check option/parameters 118 and 135
(125) (150) Valve proving cannot be optioned when fuel type is oil (fuel 1)
<ul style="list-style-type: none"> Valve proving can only be used for gas Check option/parameters 125 and 150
(126) (151) Valve proving cannot be optioned when fuel type is oil (fuel 2)
<ul style="list-style-type: none"> Valve proving can only be used for gas Check option/parameters 126 and 151
(127) (152) Valve proving cannot be optioned when fuel type is oil (fuel 3)
<ul style="list-style-type: none"> Valve proving can only be used for gas Check option/parameters 127 and 152
(128) (153) Valve proving cannot be optioned when fuel type is oil (fuel 4)
<ul style="list-style-type: none"> Valve proving can only be used for gas Check option/parameters 128 and 153
(125, 126, 127, 128) (129) (135) Post VPS cannot be optioned with NFPA Post Purge.
<ul style="list-style-type: none"> If NFPA post purge is enabled for gas, VPS can only be set for operating before burner start-up. Check option/parameters 125, 126, 127, 128, 129 and 135.
(P85) (16) Modulation exerciser cannot be used with sequencing.
<ul style="list-style-type: none"> Modulation exerciser should be used for test purposes and cannot be used with sequencing. Check option 16 and parameter 85.

Setting Conflict Message
<p>(P89) (16) Stat exerciser cannot be used with sequencing.</p> <ul style="list-style-type: none"> Stat exerciser should be used for test purposes and cannot be used with sequencing. Check option 16 and parameter 89.
<p>(P99) (P100) Graceful shutdown and assured low fire shut off not allowed.</p> <ul style="list-style-type: none"> If graceful shutdown is set, then assured low fire shut off cannot be used. Check parameters 99 and 100.
<p>(E1) (1) Water level control requires a boiler pressure sensor.</p> <ul style="list-style-type: none"> Water level control cannot be used with a hot water boiler (load/external temperature detector). Check expansion option 1 and option 1.
<p>(E1) (E3, E4) At least one analogue level sensor required.</p> <ul style="list-style-type: none"> If water level is enabled with one capacitance probe, then an external level sensor is required. Check expansion options 1, 3 and 4.
<p>(E1) (E3, E4, E5, E6) Sensor enabled but water level control disabled.</p> <ul style="list-style-type: none"> Water level control enabled must be enabled if capacitance probes, external level sensor, 2nd low probe or auxiliary water level alarm inputs are set. Check expansion options 1, 3, 4, 5 and 6.
<p>(E3, E4, E5, E6) At least two level sensing elements are required.</p> <ul style="list-style-type: none"> A minimum of two of the following level sensing elements is required: capacitance probe, external level sensor, auxiliary water level alarm input or second low probe. Check expansion options 3, 4, 5 and 6.
<p>(E4) (57) External level sensor cannot be optioned with fuel flow feedback</p> <ul style="list-style-type: none"> External level sensor cannot be used with fuel flow feedback, as they use same terminals. Check expansion option 4 and option 57.
<p>(E11) (E12) Pump turn off point must be above pump turn on point.</p> <ul style="list-style-type: none"> Pump turn off point cannot be set lower than pump turn on point. Check expansion options 11 and 12.
<p>(E17) (E40) Bypass valve cannot be optioned with solenoid top blowdown.</p> <ul style="list-style-type: none"> Bypass and solenoid top blowdown cannot be used together, as they use same terminals. Check expansion options 17 and 40.
<p>(E28) (E3) External level sensor without scaling requires a capacitance probe.</p> <ul style="list-style-type: none"> If external level sensor does not have a scale to indicate what level the 4-20mA signal represents, a capacitance probe is required. Check expansion options 3 and 38.
<p>(E40) (1) Top blowdown requires a boiler pressure sensor.</p> <ul style="list-style-type: none"> Top blowdown cannot be used with a hot water boiler (load/external temperature detector). Check expansion option 40 and option 1.
<p>(E42) (E46) TDS warning level less than TDS target.</p> <ul style="list-style-type: none"> TDS warning level cannot be set lower than the TDS target value. Check expansion options 42 and 46.
<p>(E60) (1) Bottom blowdown requires a boiler pressure sensor.</p> <ul style="list-style-type: none"> Bottom blowdown cannot be used with a hot water boiler (load/external temperature detector).
<p>(E62) (E64) Bottom blowdown reduction boiler steam production rating not set.</p> <ul style="list-style-type: none"> If bottom blowdown reduction is enabled, than steam production rating must be set. Check expansion options 62 and 64.
<p>(E62) (E120) Bottom blowdown reduction requires steam flow to be enabled.</p> <ul style="list-style-type: none"> If bottom blowdown reduction is enabled, then steam flow metering must be enabled. Check expansion options 62 and 120.

Setting Conflict Message
<p>(E80) (E82) Draught control enabled but draught servo disabled.</p> <ul style="list-style-type: none"> • Draught servomotor must be enabled for draught control. • Check expansion options 80 and 82.
<p>(E120) (57) Heat flow requires fuel flow to be optioned and commissioned.</p> <ul style="list-style-type: none"> • If heat flow function is set, fuel flow metering must be optioned and commissioned. • Check expansion 120 and option 57.
<p>(E120) (1) Steam flow requires a boiler pressure sensor.</p> <ul style="list-style-type: none"> • A boiler load/external pressure detector must be set for steam flow metering. • Check expansion option 120 and option 1.
<p>(E120) (1) Water flow requires a boiler temperature sensor.</p> <ul style="list-style-type: none"> • A boiler load/external temperature detector must be set for hot water flow metering. • Check expansion option 120 and 1.
<p>(E127) (E128) Steam flow start pressure offset must be less than stop offset.</p> <ul style="list-style-type: none"> • The steam flow start pressure offset cannot be set higher than the steam flow stop pressure offset. • Check expansion options 127 and 128.
<p>(E140) (12) Fully metered cannot be optioned with EGA trim.</p> <ul style="list-style-type: none"> • Fully metered control can be used with the EGA set as monitoring only, but not 3-parameter trim. • Check expansion option 140 and option 12.
<p>(E140) (E4) Fully metered cannot be optioned with external water level probe.</p> <ul style="list-style-type: none"> • Fully metered control cannot be used with external water level probe (terminals EX- and EX+ are required for both features). • Check expansion options 140 and 4.
<p>(E140) (E120, E129) Fully metered cannot be optioned with local heat flow.</p> <ul style="list-style-type: none"> • Fully metered control cannot be used with steam or hot water flow metering. • Check expansion options 140, 120 and 129.
<p>(E140) (E141, E143) Fuel temperature cannot be optioned with mass flow meter.</p> <ul style="list-style-type: none"> • Fuel temperature sensor cannot be used with a fuel mass flow meter in fully metered control. • Check expansion options 140, 141 and 143.
<p>(E140) (E141, E145) Fuel pressure cannot be optioned with mass flow meter.</p> <ul style="list-style-type: none"> • Fuel pressure sensor cannot be used with a fuel mass flow meter in fully metered control. • Check expansion options 140, 141 and 145.
<p>(E140) (E142, E144) Air temperature cannot be optioned with mass flow meter.</p> <ul style="list-style-type: none"> • Air temperature sensor cannot be used with an air mass flow meter in fully metered control. • Check expansion options 140, 142 and 144.
<p>(E140) (E142, E146) Air pressure cannot be optioned with mass flow meter.</p> <ul style="list-style-type: none"> • Air pressure sensor cannot be used with an air mass flow meter in fully metered control. • Check expansion options 140, 142 and 146.
<p>(E140) (150, E154) Fully metered requires gas fuel 1 to have non-zero density.</p> <ul style="list-style-type: none"> • Density must be set for gas in fully metered control. • Check option 150 and expansion options 140 and 154.
<p>(E140) (151, E155) Fully metered requires gas fuel 2 to have non-zero density.</p> <ul style="list-style-type: none"> • Density must be set for gas in fully metered control. • Check option 151 and expansion options 140 and 155.
<p>(E140) (152, E156) Fully metered requires gas fuel 3 to have non-zero density.</p> <ul style="list-style-type: none"> • Density must be set for gas in fully metered control. • Check option 152 and expansion options 150 and 156.

Setting Conflict Message	
(E140) (153, E157) Fully metered requires gas fuel 4 to have non-zero density.	<ul style="list-style-type: none"> • Density must be set for gas in fully metered control. • Check option 153 and expansion options 140 and 157.
(E140) (E142) Fully metered requires non-zero fuel flow meter scaling.	<ul style="list-style-type: none"> • Fuel flow meter must be scaled in fully metered control. • Check expansion options 140 and 142.
(E140) (E144) Fully metered requires non-zero air flow meter scaling.	<ul style="list-style-type: none"> • Air flow meter must be scaled in fully metered control. • Check expansion options 140 and 144.
(E140) (60) Fully metered does not function with fuel flow feedback tolerance.	<ul style="list-style-type: none"> • Fully metered control cannot be used with fuel flow feedback tolerance (terminals EX- and EX+ are required for both features). • Check option 60 and expansion 140.
(E140) (57) Fully metered requires fuel flow metering to be enabled (1).	<ul style="list-style-type: none"> • Fuel flow metering must be enabled when using fully metered control. • Check option 57 and expansion option 140.
(E140) (76) Fully metered cannot use air trim on channel 5 (VSD).	<ul style="list-style-type: none"> • Air trim cannot be used on channel 5 VSD in fully metered control. • Check option 76 and expansion option 140.
(86) (E129) Servo channel 1 via I/O unit cannot be optioned with heat flow sensors via I/O unit.	<ul style="list-style-type: none"> • Heat flow sensors from the I/O unit cannot be optioned with servo channel via I/O unit. • Check option 86 and expansion 129.
(87) (E129) Servo channel 2 via I/O unit cannot be optioned with heat flow sensors via I/O unit.	<ul style="list-style-type: none"> • Heat flow sensors from the I/O unit cannot be optioned with servo channel via I/O unit. • Check option 87 and expansion 129.
(88) (E129) Servo channel 3 via I/O unit cannot be optioned with heat flow sensors via I/O unit.	<ul style="list-style-type: none"> • Heat flow sensors from the I/O unit cannot be optioned with servo channel via I/O unit. • Check option 88 and expansion 129.
(89) (E129) Servo channel 4 via I/O unit cannot be optioned with heat flow sensors via I/O unit.	<ul style="list-style-type: none"> • Heat flow sensors from the I/O unit cannot be optioned with servo channel via I/O unit. • Check option 89 and expansion 129.
(E81) (E129) Servo channel 7 via I/O unit cannot be optioned with heat flow sensors via I/O unit.	<ul style="list-style-type: none"> • Heat flow sensors from the I/O unit cannot be optioned with servo channel via I/O unit. • Check expansion options 81 and 129.

4.5 Forced Commission Reasons

In addition to when there is a setting conflict, the MM will be forced into commission mode if any of the forced commission reason occurs.

Forced Commission Message
Fuel not commissioned.
<ul style="list-style-type: none"> Selected fuel must be commissioned.
Servo configuration does not match commissioning.
<ul style="list-style-type: none"> Option 8 and/or expansion option 80 do not match the last commission settings.
VSD configuration does not match commissioning.
<ul style="list-style-type: none"> VSD settings for channels 5 and 6 must be the same as the last commission settings.
Golden start optioned but not commissioned.
<ul style="list-style-type: none"> Commission golden start position (see section 3.4.8).
FGR optioned but not commissioned.
<ul style="list-style-type: none"> Commission FGR start position (see section 3.4.9).
Trim channel does not match commissioning.
<ul style="list-style-type: none"> Option 76 trim channel must be the same as the last commission settings.
Fuel/air-rich trim ranges changed.
<ul style="list-style-type: none"> Parameter 13 and/or parameter 19 do not match last commission settings.
BC Option/parameter mismatch.
<ul style="list-style-type: none"> BC options 110 - 160 must be set the same as their corresponding parameters.
Invalid option value.
<ul style="list-style-type: none"> An option value is outside the allowed range.
Invalid parameter value.
<ul style="list-style-type: none"> A parameter value is outside the allowed range.
Invalid expansion option value.
<ul style="list-style-type: none"> An expansion option value is outside the allowed range.
Options have been reset.
<ul style="list-style-type: none"> Option settings have been reset due to data lost in an EEPROM error.
Parameters have been reset.
<ul style="list-style-type: none"> Parameter settings have been reset due to data lost in an EEPROM error.
Expansion options have been reset.
<ul style="list-style-type: none"> Expansion option settings have been reset due to data lost in an EEPROM error.
VPS sensor not commissioned.
<ul style="list-style-type: none"> Gas pressure sensor has been enabled but not commissioned.
Commissioned gas pressure during valve proving too low.
<ul style="list-style-type: none"> Gas pressure stored during valve proving is less than option/parameters 133 and/or 136.
Commissioned running gas pressure too low.
<ul style="list-style-type: none"> Gas pressure at one or more commissioned points is less than option/parameter 136.
APS sensor not commissioned.
<ul style="list-style-type: none"> Air pressure has been enabled but not commissioned.
Commissioned air pressure too low.
<ul style="list-style-type: none"> Air pressure at one or more commissioned points is less than option/parameters 147 and/or 149.
IR Upload was completed successfully, check configuration then restart.
<ul style="list-style-type: none"> Check data has uploaded successfully before restarting in run mode.

Forced Commission Message
Options and/or parameters reset to default values. Check configuration then restart.
<ul style="list-style-type: none"> Reset of setting using option/parameter 160. Set/check settings and restart.
First outs are optioned but not configured. Check configuration then restart.
<ul style="list-style-type: none"> Configure first outs and restart.
Too many sensors require commissioning.
<ul style="list-style-type: none"> Gas and air pressure sensors can be optioned on after fuel has been commissioned, but only one a time before completing commissioning process for each.
Draught servo minimum angle greater than a commissioned draught servo angle.
<ul style="list-style-type: none"> One or more commissioned points for draught servomotor is lower than expansion option 83.c
Capacitance probe not commissioned.
<ul style="list-style-type: none"> Capacitance probe has been enabled but not commissioned.
Capacitance probe serial number does not match commissioning.
<ul style="list-style-type: none"> Capacitance probes have changed, recommission water level.
External level sensor not commissioned.
<ul style="list-style-type: none"> External level sensor has been enabled but not commissioned.
VSD1 Feedback variation too small. Maximum VSD fault tolerance is –
<ul style="list-style-type: none"> Difference between smallest and largest channel 5 VSD feedback is less than option 99 (this message will display required value for option 99 to run).
VSD 2 Feedback variation too small. Maximum VSD fault tolerance is –
<ul style="list-style-type: none"> Difference between smallest and largest channel 6 VSD feedback is less than option 109 (this message will display a required value for option 109 to run).
Draught control optioned but not commissioned.
<ul style="list-style-type: none"> Draught control has been enabled but not commissioned.
Fully metered optioned but not commissioned.
<ul style="list-style-type: none"> Fully metered control has been enabled but not commissioned.
Fully metered configuration does not match commissioning.
<ul style="list-style-type: none"> One or more sensors used for fully metered control that were not present during commissioning are now enabled.

4.6 Troubleshooting and Further Information

4.6.1 UVShutter Faults

UV shutter fault- there are two LED's on the back of the self-check UV. The red LED indicates the presence of a flame; the yellow LED indicates shutter operation. The red LED will flicker in the presence of UV light. Every 60 seconds the yellow LED will come on, indicating that the shutter is closing. The red LED should then extinguish briefly. If this is not happening check the wiring to self-check UV sensor:

Green wire = Terminal 22
 Yellow wire = Terminal 21
 Blue wire = Terminal 50
 Red wire = Terminal 51

4.6.2 UV Problems

If the red LED's fail to illuminate but the burner operates, it is likely that the 2 wires are crossed. This must be corrected. Once corrected a full flame signal strength will be displayed/registered.

The Autoflame UV software utilises early spark termination within the internal flame safeguard control. Therefore, detection of the ignition spark is allowed. During start-up the ignition is de-energised and the pilot flame must be proven without the spark before the main fuel valves are open (safety shut off). Due to the above statement it is not necessary to have a sight tube on the UV for pick-up. This, in fact, will drastically reduce the flame pick-up.

If insufficient UV is detected, it is advised to use a swivel mount assembly (UVM60003/UVM60004) in order to obtain maximum pick-up. This will allow the commissioning engineer to reliably sight the UV for optimum performance and trouble free operation.

Note: Under no circumstances is a non-Autoflame UV scanner permitted to be used. This is in breach of all codes and approvals associated with the Autoflame combustion management system. This may lead to serious equipment damage, critical injury or death.

If a non-Autoflame scanner is required then please contact Autoflame directly for technical support. For more information on UV scanners, please refer to MM Flame Safeguard and Operation.

4.6.3 Snubbers


The Autoflame system has internal components which protects itself against voltage/current spikes and electrical interference. In some installations this internal protection is not enough, especially when the main fuel valve Terminals 60 and 61 have been connected to older gas valves and voltage/current spikes have occurred when the valves have been switched on or off. This can cause internal damage to the MM Snubbers can be used on these old gas valves to protect the MM from these spikes; they should be fitted across the power terminals of the gas valves. Please contact Autoflame Sales for more information.

4.6.4 Channel Positioning Error

The 'Channel Positioning' MM Error is caused by incorrect wiring and incorrect servomotor position. In addition to checking the wiring, and zeroing the potentiometer, please also check that the correct voltage is supplied to the servomotors, which should be $\pm 10\%$ of the required voltage, and the unit is earthed properly. This can cause hunting issues if not at the required voltage or incorrect earthing.

4.6.5 Input Fault

The 'Input Fault' MM Error relates to a fault with the power supply going to the MM. The MM verifies the power supply going to the unit; the mains inputs are sampled to check the DC voltage. The diagram below illustrates the AC voltage that comes in through the power supply with the detected signal (digital input).



The MM checks the ON state of the digital signal in the mains input; the ON state of the digital input should be 50%. This means that the digital input should be in the ON state for a half-wave of the AC signal. The OFF state is safe. If the MM sees the digital input being ON for more than 75% across a sample period, then it will get stuck in an unsafe state. This will cause an Input Fault lockout to occur.

If this lockout persists, the mains input should be checked. To troubleshoot this issue, please check for any DC voltage in the mains voltage and contact your local power supplier.

5 STANDARDS

The Mk8 MM has been tested and approved to the following standards:

UL 372, 5th Edition

C22.2 No. 199 - M89

BS EN 298:2012

BS EN 12067-2:2004

BS EN 1643:2014

BS EN 1854

ISO 23522:2007

AS 4625 - 2008

AS 4630 - 2005



ZANTINGH

Autoflame Engineering Ltd
Unit 1-2 Concorde Business Centre
Airport Industrial Estate, Wireless Road
Biggin Hill, Kent TN16 3YN
United Kingdom
+44 (0) 845 872 2000
www.autoflame.com

AUTOFLAME[®]